

Barristers and Solicitors

Scott A. Stoll
Direct: 416.865.4703
E-mail: sstoll@airdberlis.com

February 15, 2012

BY COURIER

Kirsten Walli Board Secretary 2300 Yonge Street 27th Floor, Box 2329 Toronto, ON M4P 1E4

Dear Ms. Walli:

Re: EB-2012-0060 - Application to Drill Wells into a Designated Storage Area

On Tuesday February 14th, 2012, Enbridge Gas Distribution Inc. ("Enbridge") applied to the Ministry of Natural Resources ("MNR") for permission to drill four (4) observation wells within the Kimball-Colinville designated storage area. Pursuant to section 40 of the *Ontario Energy Board Act, 1998*, S.O. 1998 c.15, Schedule B, the Minister of Natural Resources is obligated to refer the application for the granting of a licence related to a well in a designated storage area to the Ontario Energy Board for a report.

These are observation wells therefore and do not require a pipeline to connect to the existing storage network and no leave to construct application is required.

Enclosed please find the observation well applications filed by Enbridge with the MNR.

If you require further information regarding this matter please contact the undersigned at your earliest convenience.

Yours truly,

AIRD & BERLIS LLP

Original Signed

Scott A. Stoll

SAS/hm

11902447.1

Gas Storage Operations 3595 Tecumseh Road Mooretown, ON NON 1M0 (519) 862-1473 (519) 862-1168 Fax



February 14th, 2012

Ministry of Natural Resources Petroleum Resources Centre 659 Exeter Road London, Ontario N6E 1L3

Attention: Manager, Petroleum Operations Section

Subject: Submittal of Four Drilling Applications for Observation Wells in the

Kimball-Colinville Designated Storage Area

Enclosed, please find four (4) drilling applications for the proposed observation wells to be drilled in the Kimball-Colinville Designated Storage Area (DSA).

For each well application you will find 2 copies of the Form 1, 2 copies of the Wellsite Survey and 2 copies of the Drilling Program plus the drilling application fee. It is our hope to start the drilling of the wells by March 15th, 2012. We would be pleased to meet with you to review or clarify any portion of the application.

We have been in contact with the Ontario Energy Board (OEB) to inform them of the applications for 4 Observation Wells. The OEB has assigned docket number EB-2012-0060. For your information, Enbridge has also submitted a package containing the drilling applications to the OEB.

If any further information is required please contact the undersigned at 519-862-6032.

Yours truly,

{ORIGINAL SIGNED}

Kathy McConnell, P.Geo Senior Project Geologist

Encls.



location, and he/she has authority to bind the operator.

08.Feb.12

04.Apr.62

Name

Company

J.E. Sanders

Enbridge Gas Distribution Inc.

Signature

Title

(Original Signed)

Director, Storage Operations

Date (d/m/y)

Date of Birth


Oil, Gas and Salt Resources Act

Application for a Well Licence

Filed: 2012-02-15 EB-2012-0060 Attachment 3 Page 1 of 25

v.2010-07-01 To the Minister of Natural Resources Form 1 The undersigned operator applies for a well licence under the Oil, Gas and Salt Resources Act and the Regulations thereunder and submits the following information, together with the application fee of \$100 + 13% HST. TKC # 65 Moore 1-14-IV Target Formation A-1 Carbonate Purpose of Proposed Well (Well Type) Observation Well Tel # 519-862-1473 Fax # 519-862-1168 Enbridge Gas Distribution Inc. 2. OPERATOR Street Address 3595 Tecumseh Road Day. Mooretown 1111 NON 1MO Mailing Address 3595 Tecumseh Road City Mooretown Prov ON Postar Gode, NON 1MO 519-862-6032 Contact Name Kathy McConnell Contact Tel # Township County Lambton Moore 3. LOCATION Tract 1 Lot 14 Concession IV Lake Erie: €#ak Yraci Liosepullieure Ha 42⁰ 48' 42.407" Bottom-hole Lat. 113.05 m North South X Latitude 42° 48' 42.407" Surface location. metres from Bottom-hale Long. 335.60 m East X West Longitude 82° 20' 19.581" 82° 20' 19.581" Lot Boundaries Yes X No Yes No X Off-target? Within 1.6 km of Designated Storage Area? Horizontal Directional Deepening Re-entry 4. WELL PARTICULARS Vertical X Lateral Rotary X Cable X Well to be cored? Yes No X Formation at TD A-1 Evaporite Rig Type: 190.45 Proposed Depth 688.0 Proposed Depth TVD 688.0 Proposed Start Date Ground Elevation Tel# 5. LANDOWNER Pestel Code Street Address The landowner herby provides consent for the collection of their (Original Signed) personal Information, via the operator, as per Section 12 of this form. Landowner Signature: Pooling of the Spacing Unit or unitization of the Unit Area shown on the attached well location plan Yes X No has been completed (see Ont. Reg. 245/97 definitions for "pooled spacing unit" and "unitize") Tel # 519-695-6062 / 519-689-4692 6. DRILLING CONTRACTOR T.W. Marsh Well Drilling and Servicing / Bradco Drilling Inc. Bothwell / Merlin ON Forth Code NOP 2C0 / Box 53 / 14 Hattie St., Box 99 FILL Olty NOP 1WO 7. PROPOSED CASING AND CEMENTING PROGRAM CASING SETTING INFORMATION Casing O.D. New, Used Setting **Setting Formation** How Cement Cement Top Weight Grade or in-hole Depth TVD Set Type KB/RF (mm) (mm) (kg/m) 81.10 LS New 43 Kettle Point Driven nil nil 340 340 surface G 48.06 New 58 Kettle Point Cement 312 244 H40 222 178 29.76 **J55** New 391 F Shale Cement G surface G 647.5 A-2 Anhydrite Cement surface 114 15.62 J55 New 159 8. BLOW-OUT PREVENTION EQUIPMENT 9" 2M Annular Preventor 7-1/16" 3M Annular Preventor and Double Gate Harrison Pensa LLP Total # Unplugged Wells 162 Current Balance \$70,000 9. WELL SECURITY Name of Trustee ____ 10. REMARKS 11. ENCLOSURES Fee X Location Plan X (Land wells only) Drilling Program X 12. NOTICE OF COLLECTION The Ministry of Natural Resources is collecting your personal information under the authority of the Oil, Gas and Salt Resources Act. Any personal information provided on this application will be used for licensing and law enforcement purposes only and will be protected in accordance with the Freedom of Information and Protection of Privacy Act. If you have questions about use of your personal information, please contact the Policy and Program Officer, Petroleum Resources Centre, Ministry of Natural Resources, 659 fixeter Road, London Nobill A, 519-873-4638. 13. AUTHORITY The undersigned certifies that the information provided herein is complete and accurate, the operator has the right to drill or operate a well in the above

Filed: 2012-02-15 EB-2012-0060 Attachment 3 Page 2 of 25



Filed: 2012-02-15 EB-2012-0060 Attachment 3 Page 3 of 25

TKC # 65, Moore 1-14-IV

DRILLING PROGRAM

TABLE OF CONTENTS

SECTION 1.0 GENERAL DATA

Section 1.1 Well Summary
Section 1.2 Special Notes
Section 1.3 Contact Numbers

SECTION 2.0 GEOLOGICAL PROGNOSIS

SECTION 3.0 CASING AND CEMENTING SUMMARY

Section 3.1 Summary

Section 3.2 Wellbore Diagram
Section 3.3 Wellhead Information

SECTION 4.0 DRILLING PROCEDURES

Section 4.1 Pre-Spud

Section 4.2 Conductor Casing

Section 4.3 Surface Hole and Surface Casing

Section 4.4 Intermediate Hole and Intermediate Casing Section 4.5 Production Hole and Production Casing

Section 4.6 Main Hole

Section 4.7 Loss Circulation Procedure

SECTION 5.0 REPORTING PROCEDURES

Section 5.1 Tower Sheets Section 5.2 Worker Injury

SECTION 6.0 SAFETY AND PROCEDURES

Section 6.1 General Safety Section 6.2 Well Control

Filed: 2012-02-15 EB-2012-0060 Attachment 3 Page 5 of 25

SECTION 1.0 - GENERAL DATA

Section 1.1 - Well Summary

Well Name:

TKC # 65 Moore 1-14-IV

Operator:

Enbridge Gas Distribution Inc.

Surface Location:

Tract 1, Lot 14, Con. 4, Moore Twp, Lambton County

Surface Coordinates:

113.05m South; 335.60m East

Ground Elevation:

190.45m

KB Elevation:

191.75m

Total Depth:

688m

Target Formation:

A-1 Carbonate

Logging Program:

Gamma Ray / Neutron from TD to base of Surface Casing

Porosity / Density Log A-2 Anhydrite to TD

CBL-GR – 114mm casing Vertilog – 114mm casing

Spud Date:

March 15th, 2012

Duration:

45 days

Section 1.2 - Special Notes

1. Safety of personnel and environment is our primary concern. Section 6.1 of this program, outlines Enbridge's general safety requirements which obliges all personnel on the wellsite to follow the Occupational Health and Safety Act and Regulations (Ministry of Labour) and the Oil, Gas & Salt Resources Act and Regulations (Ministry of Natural Resources). Safety and/or environmental ("tailgate") meetings shall be conducted as per Section 6. Wellsite Supervisor shall conduct daily 'walk around' inspections of the equipment on site and record the results on the daily reports. Please refer to Section 5.2 for the procedure to be followed if a worker injury occurs.

 The Wellsite Supervisor has authority over all activities conducted on the drilling location. The Wellsite Supervisor shall ensure that all applicable regulations and policies (MNR, MOL, MOEE, and Enbridge) are followed and that all permits are kept on site and/or signed off as required.

Filed: 2012-02-15 EB-2012-0060 Attachment 3 Page 6 of 25

- 3. All operations are to be to MNR standards.
- 4. BOPs are to be installed, maintained and used as per MNR requirements. Testing of the BOPs must be in accordance with Section 6.2 of this program.
- 5. Tower sheets must be completed daily and will include the information listed in Section 5.1 of this program. The Wellsite Supervisor will complete daily reports and forward the reports to Enbridge's office by 10am the following day.
- 6. The production casing will be set in the A-2 Anhydrite to allow for an effective cement job and successful pressure testing, prior to penetrating the A-1 Carbonate formation.

Section 1.3 - Contact Numbers

Enbridge Gas Distribution Inc.

Kathy McConnell Senior Project Geologist Office: 519-862-6032 Fax: 519-862-1168 Cell: 519-312-2168 kathy.mcconnell@enbridge.com Paul Druet Manager, Reservoir Office: 519-862-6016 Development Fax: 519-862-1168 Cell: 519-383-4012 paul.druet@enbridge.com Terry Chupa Land Administrator Office: 519-862-6008

Fax: 519-862-1168 Cell: 519-384-0215 terry.chupa@enbridge.com

Control Room Office: 519-862-6012

Drilling Supervisor:

Steve Thompson Cell: 519-383-5404

omniconsulting@rogers.com

Wayne Bolton Cell: 519-312-8437

kegconsulting@aim.com

Filed: 2012-02-15 EB-2012-0060 Attachment 3 Page 7 of 25

Geologist:

Office: 519-472-4776 Neil Hoey

Fax: 519-472-4776 Cell: 519-649-6918 neil hoey@hotmail.com

Cable Tool Rig - Terry Marsh Well Drilling & Servicing

Office: 519-695-6060 Terry Marsh Owner / Operator

> Fax: 519-695-6464 519-359-9804 Cell: twmarshca@yahoo.com

Rotary Rig - Bradco Drilling Inc.

Office: 519-689-4692 Brad Stevenson Owner / Operator

> 519-689-7516 Fax: 519-358-3742 Cell: bradco@ciaccess.com

Cementing

Black Creek Well Service Office: 519-882-4732 Ian Veen

> President 519-834-2941

> > 519-834-2466 Fax: Cell: 519-686-4645

Schlumberger Canada Office: 519-652-5053 Jay Rookes

Engineer-In-Charge Fax: 519-652-6002

rookes1@slb.com

Casing & Wellheads - Wellmaster Pipe & Supply Inc.

Office: 519-688-0500 Sales Representative Andy Arnoczki

519-688-0563 Fax: 519-537-0559 Cell: aarnoczki@wellmaster.ca

Inside Sales Office: 519-688-0500 Bill Hedges

519-688-0563 Fax: bhedges@wellmaster.ca

Graham Shone **Operations Manager** Office: 519-336-9797

> 519-336-9733 Fax: Cell: 519-331-2534

gshone@cefranklin.com

Filed: 2012-02-15 EB-2012-0060 Attachment 3 Page 8 of 25

Larry Rushton Owner Office: 519-326-8884 Fax: 519-326-8882

rushtonsupply@sympatico.ca

Wireline Services

Gord MacKenzie Baker Atlas Office: 519-332-8030 Base Manager Fax: 519-332-4714

Cell: 519-339-6783

gord.mackenzie@bakerhughes.com

Dave Tipping Weatherford Canada -Office: 519-683-2010 Wireline & Logging 519-683-2577 Fax:

Services Cell: 519-436-3541 Station Manager dave.tipping@canada.weatherford.com

Snubbing Services

Derrick Jacobson President Office: 877-829-7242 Quattro Energy Services Fax: 403-720-6319

Cell: 403-828-7242 derrick@quattroenergy.ca

Jeff Redmond **Team Snubbing Services** Office: 403-314-4220

Fax: 403-844-2148 Cell: 403-896-8363

jredmond@teamsnubbing.com

Water Hauling

Melvin McKeegan President Office: 519-864-1037

McKeegan Trucking Fax: 519-864-1036 Limited Cell: 519-490-4028

Denis Marcus President Office: 519-695-3735 Harold Marcus Limited Fax: 519-695-2249

Cell: 519-380-5238 dmarcus@haroldmarcus.com

Aaron Verstraete President Office: 519-676-6747 Oil Patch Services Fax: 519-676-7932

Cell: 519-380-5473 ops.aaron@bellnet.ca

Rental Equipment

Derrick Holland Wheatley Wireline Services Office: 519-825-3680 Ltd. Fax: 519-825-9348

Cell: 519-322-8439 dholland891@hotmail.com

Filed: 2012-02-15 EB-2012-0060 Attachment 3 Page 9 of 25

Wade Glass Wheatley Wireline Services Office: 519-825-3680 519-825-9348 Ltd. Fax: Cell: 519-322-9275 Orval Beam Orval L. Beam Limited Office: 519-436-0164 Operations Manager 519-436-0164 Fax: Tank Rentals Cell: 519-436-4801 JW Seward Enterprises Ltd Office: 519-867-5526 Jim Seward Crane Trucks, Steel Plates Fax: 519-867-5312 519-332-7689 Cell:

Welders - St. Clair Mechanical

John Dawson President Office: 519-864-0927 Fax: 519-864-0801 Cell: 519-330-9672

Government & Other Agencies

MOEE

MNR Petroleum Resources Centre Office: 519-873-4634
Fax: 519-873-4645

ogsr.mnr.gov.on.ca

MOL Health & Safety 1-800-265-1676

Spill Reporting

Health & Safety Inspector Office: 519-646-3238

Fax: 519-672-0268

1-800-268-6060

Richard Ostrowski Oil, Gas & Salt Resources Office: 519-686-2772 Library Fax: 519-686-7225

Library Fax: 519-686-7225 richard@ogsrlibrary.com

Police, Fire & 911 Ambulance

SECTION 2.0

GEOLOGICAL PROGNOSIS

County: Lambton

Township: Moore

Concession: IV

Lot: 14

Tract: 1

Elevation: 190.2m Estimated

Formation	Тор	Elevation	Thickness	Gas	Oil	Water
K.B.	0.0	191.7	1.5			
Drift	1.5	190.2	41.2			Fresh@41.1m
Kettle Point	42.7	149.0	36.8			
Hamilton	79.5	112.2	79.9			
Dundee	159.4	32.3	28.6			
Lucas	188.0	3.7	149.7			Sulphur@196.6m
Amherstburg	0.0	0.0	0.0			
Bois Blanc	0.0	0.0	0.0			
Bass Islands	336.8	-146.0	25.3			
G-Shale	362.1	-171.3	23.8			
F-Shale	385.9	-195.1	47.8			
F-Salt	0.0	0.0	0.0			
E-Carbonate	433.7	-242.0	26.2			
D-Salt	459.9	-269.1	8.9			
C-Shale	468.8	-278.0	24.7			
B-Salt	493.5	-302.7	82.6			
A-2 Carbonate	576.1	-385.3	42.0			
A-2 Salt	618.1	-427.3	29.0			
A-2 Anhydrite	647.1	-456.3	0.6			
A-1 Carbonate	647.7	-456.9	38.7	648m; 653m		
A-1 Evaporite	686.4	-495.6	3.4			
TD	687.4	-496.6				

^{***}Note: Prognosis with TVD tops.
***Note: used Kimball No. 5 to build prog


SECTION 3.0 - CASING AND CEMENTING SUMMARY

Section 3.1 - Summary

Hole Size (mm)	Casing Size (mm)	Casing Grade	Casing Weight (kg/m)	Setting Depth (mKB)	How Set
340	340	LS	81.10	43	Driven – cement squeeze if necessary
312	244	H40	48.06	58	Cemented to surface with 100% excess Class G 0-1-0 cement + 2 - 3% CaCl ₂
222	178	J55	29.76	391	Cemented to surface with Class 'G' 0-1-8% plus 1 to 3% CaCl ₂ , followed by Class 'G' neat cement plus 1 to 3% CaCl ₂ . Cement volumes will be calculated with a 50% excess- gel cement and 30% excess – neat cement. Depending upon hole conditions, consideration may be given to running thixotropic cement plus additional loss circulation materials, across porous zone(s).
159	114	J55	15.62	647.5	Cemented to surface with Class 'G' 0-1-0% plus 1 to 2% CaCl ₂ plus 10% NaCl. Cement volumes will be calculated with a 50% excess on the open hole section and 30% excess on the cased hole section.

Main Hole: 98mm open hole will be drilled from 647.5m to 688m

Section 3.2 - Wellbore Diagram



Filed: 2012-02-15 EB-2012-0060 Attachment 3 Page 13 of 25

Section 3.3 - Wellhead Summary

Weatherford 13.8 MPa Wellhead:


244mm x 279mm slip on weld on casing bowl for BOP installation

178mm x 229mm slip on weld on casing bowl

229mm x 179mm spool c/w 2 gate valves on side outlets

179mm 13.MPa x 179mm x 20.7 MPa double studded adapter

152mm ANSI 900 Cameron Grove full port ball valve



Filed: 2012-02-15 EB-2012-0060 Attachment 3 Page 14 of 25

SECTION 4.0 - DRILLING PROCEDURES

Section 4.1 - Pre Spud

1. Fresh Water Well Samples

Obtain samples from all fresh water wells located within a 750 metre radius of the proposed well. Have routine water analysis done on all water samples by an independent laboratory in Sarnia. Ensure that copies of these reports are placed in the well files in Enbridge's office

2. Site Preparation

Prepare drilling location as follows:

- a. Locate all drainage tiles crossing lease area
- b. Strip and properly stock pile all soil from the lease
- c. Cut, block and divert drainage tiles as required
- d. Construct adequate berms around lease and access road as required

3. Government Notification of Spud

48 hours prior to spud, notify the Ministry of Natural Resources – Petroleum Resources Section by fax @ (519) 873 – 4645 of the date of commencement of drilling operations

4. Signs

Install rig signs on access road to lease.

5. Safety Meeting

Conduct a pre-spud safety meeting for Rig crews. Tool push and all crewmembers must be present. A similar meeting shall be conducted with the remaining crew(s) as they come on duty. Additional safety meetings shall be conducted as per Section 6.1 of this program.

Section 4.2 - Conductor Casing

1. Drilling Method

Move in and rig up Cable Tool Rig. Measure and record the distance from RF to ground and the RF elevation – include these measurements on the tower sheets and the daily report. Drill and drive 340mm casing to bedrock, to an approximate depth of 43m. Note any occurrence of water and record type of water, depth encountered, and static level of water and/or flow rate. If fresh water is encountered during

drilling, the well must be bail tested for at least 15 minutes, after the casing is landed, to ensure that the fresh water has been shut-off. If the fresh water has not been shut-off, contact Enbridge's office and be prepared to perform a cement squeeze as per Enbridge's requirements.

2. Cement Squeeze (if necessary)

If fresh water is found in the drift and is not shut-off by the conductor casing, a flow rate will be established and a cement squeeze will be performed, using the cement volumes determined by Enbridge. Wait on cement 12 hours and bail the hole dry and monitor the well for at least 15 minutes to determine if the water has been shut-off. If necessary, the process will be repeated until the water is shut-off.

Section 4.3 - Surface Hole & Surface Casing

1. Drilling Method

Drill a 312mm hole 15 metres ± into the Kettle Point formation, to an approximate depth of 58m. Ensure that drill cutting samples are taken every 3 metres and placed in the sample bags provided by the Ministry of Natural Resources. The sample bags must be labeled with the well name, Township, Lot, Concession and Enbridge's name. Record on daily drilling reports any influx of fluids and/or hydrocarbons, static levels, pressures and any unusual hole conditions.

2. Casing Installation

Depending upon hole conditions encountered, the 244mm casing will be run in the following manner:

- Texas Shoe on bottom of first joint
- Centralizers on the top and bottom of the first joint and coincident with the shoe of the conductor casing
- 244mm casing to surface

3. Cementing Procedures

Move in and rig up Cementers. Ensure pressure recorder is rigged in and serviceable. Pressure charts will be attached to the job ticket. Conduct a pre-job safety meeting to confirm volumes and procedures. Establish circulation using pump truck. The casing and the hole will be circulated with fresh water for 15 minutes to clean the borehole and to fill the casing and hole prior to cementing. Pressure test surface equipment to 14 MPa. Ensure that preflush and mix water are from a clean source and that the water trucks are uncontaminated. Pump preflush of 2.0m³ of fresh water, with the addition of loss circulation material if necessary. Ensure that a minimum of 4 cement samples are taken and represent the cement at the beginning, middle and end of the cement job. Mix and pump sufficient Class 'G' 0-1-0% cement plus 2 to 3% CaCl₂

with a density of 1901 kg/m³ to cement the casing to surface with 100% excess. Displace cement with fresh water – ensure that cement is under displaced and that the bottom joint of casing is full of cement. Shut-in cementing valve at surface and wait on cement at least 12 hours before slacking off casing.

- 4. Install 244mm x 279mm slip on weld on casing bowl for BOP installation. Arrange to have surface hole cuttings solidified and then disposed in an approved manner.
- Release the Cable Tool Rig.

Section 4.4 - Intermediate Hole & Intermediate Casing

1. BOP Installation and Pressure Testing

Move in and rig up Rotary Rig. Measure and record the distance from KB to ground and the KB elevation – include these measurements on the tower sheets and the daily report.

Install Class A (Rotary) BOPs as per MNR requirements. After BOPs are installed and the cement samples indicate that the cement is competent, the rig will proceed to pressure test the BOPs, casing and shoe. Pressure test casing and each component of the BOPs as per Section 6.2. After successfully pressure testing the BOPs and casing, drill out cement and 0.5m of new formation and conduct a PIT, with the hole full of fresh water, using a bottom hole pressure equivalent to 18 kPa/m.

2. Drilling Method

Drill a 222mm hole with fresh water to 5m ± into the F Shale formation, to an approximate depth of 391m. Notify Geologist 12 hours in advance of reaching intermediate casing point, so that they can be on site to determine the proper casing setting depth. When casing setting depth has been determined, circulated the hole clean. Perform a flow check prior to tripping and strap out of the hole. Fast tripping of the drill string is to be avoided in order to eliminate high annular velocities, pressure surges and swabbing (maximum rate of 27 metres per minute). Keeping the hole full of fluid, trip out of the hole and laydown bottom hole assembly and depending upon rotary rig type, standback or laydown drill collars and drill pipe.

The potential for loss circulation exists while drilling through the Detroit River formations (Lucas and Amherstburg formations). If loss circulation is encountered use the loss circulation contingency program located in Section 4.7. Note all lost circulation intervals and monitor and record fluid loss volumes. If pit fluid must be hauled to disposal, keep solid content to a minimum to reduce costs.

Ensure that drill cutting samples are taken every 3 metres and placed in the sample bags provided by the Ministry of Natural Resources. Record on daily tower sheets

Filed: 2012-02-15 EB-2012-0060 Attachment 3 Page 17 of 25

any influx of fluids and static levels (water and/or hydrocarbons), gas and/or any unusual hole conditions.

3. Casing Installation

Ensure that the threads are protected while hoisting casing to the floor. Drift all casing prior to running the casing in the well and apply proper API make-up torque to each connection.

Depending upon hole conditions encountered, the 178mm casing will be run in the following manner:

- Guide shoe
- 178mm joint of casing
- 178mm Float Insert or Float Collar
- Tack weld guide shoe, float collar and bottom 2 joints and use API modified pipe dope on all connections
- Centralizers will be installed one metre above the guide shoe, over the bottom of the first 2 collars and every 5 joints to surface
- 178mm casing to surface

4. Cementing Procedures

Move in and rig up Cementers. Ensure pressure recorder is rigged in and serviceable. Pressure charts will be attached to the job ticket. Conduct a pre-job safety meeting to confirm volumes and procedures. Fill hole and establish circulation using pump truck. The casing and the hole will be circulated with fresh water for 15 minutes to clean the borehole and to fill the casing and hole prior to cementing. Pressure test surface equipment to 14MPa for 10 minutes. Preflush and mix water must be obtained from a clean source and the water trucks must be uncontaminated. Pump preflush of 3.0m³ of fresh water, with the addition of loss circulation material if necessary. Ensure that a minimum of 4 cement samples are taken and represent the cement at the beginning, middle and end of the cement job. Mix and pump sufficient 0-1-8 Class 'G' cement plus 1 to 3% CaCl₂ (50% excess) followed by 0-1-0 Class 'G' cement plus 1 to 3% CaCl₂ (30% excess) to cement casing to surface. Depending upon the severity of the loss circulation zones, thixotropic cement with additional loss circulation materials may be used to cover the loss zone. If there are no cement returns to surface, a feed rate will be established and the annulus will be grouted to surface. Drop wiper plug and displace cement and bump plug to 3.5 Mpa over final pumping pressure – do not exceed 60% of internal yield pressure of casing. Once plug is bumped and it is determined that the float is holding, bleed casing pressure back to final pumping pressure, close casing valves and bleed off surface line pressure and wash out BOPs. Wait on cement 24 hours before slacking off casing. Remove 244mm x 279mm casing bowl and install 178mm x 229mm casing bowl on the 178mm casing.

Section 4.5 - Production Hole & Production Casing

1. Pressure Testing

Check cement samples for hardness – if cement samples are set to the satisfaction of the Wellsite Supervisor, proceed with installation of the BOPS. Install Class B (Rotary) BOPs as per MNR requirements on 178mm casing bowl. After BOPs are installed and the cement samples indicate that the cement is competent, the rig will proceed to pressure test the BOPs, casing and shoe. Pressure test casing and each component of the BOPs as per Section 6.2. After successfully pressure testing the BOPs and casing, drill out cement and 0.5m of new formation and conduct a PIT, with the hole full of fresh water, using a bottom hole pressure equivalent to 18 kPa/m.

2. Drilling Method

Drill a 159mm hole using brine to prevent the dissolution of the salt layers. Ensure that drill cutting samples are taken every 3 metres and placed in the sample bags provided by the Ministry of Natural Resources. Record on daily tower sheets any influx of fluids and static levels (water and/or hydrocarbons), gas and any unusual hole conditions.

Prior to penetrating the A-2 Carbonate, the Wellsite Geologist and Wellsite Supervisor must be on-site and a BOP drill shall be completed to familiarize all on-site personnel with the proper procedures.

Drill a 159mm hole $1 \pm$ metres into the A-2 Anhydrite formation, to an approximate depth of 647.5m. The final casing point will be determined by the Wellsite Geologist.

If the reef pressure is above 7000kPa, drilling will be suspended and the rig will be moved off location after the 114mm casing is installed and cemented. The rig will be brought back onto location to complete the drilling of the well when the reef pressure is below 7000kPa.

3. Casing Installation

Ensure that the threads are protected while hoisting casing to the floor. Drift all casing prior to running the casing in the well and apply proper API make-up torque to each connection.

Depending upon hole conditions encountered, the 114mm casing will be run in the following manner:

- Guide shoe
- 114mm joint of casing
- Float Insert or Float Collar

Filed: 2012-02-15 EB-2012-0060 Attachment 3 Page 19 of 25

- Tack weld guide shoe, float collar and bottom 4 joints and use API modified pipe dope on all connections
- Centralizers will be installed on bottom 5 joints of casing on every 5th joint to surface
- 114mm casing to surface

4. Cementing Procedures

Move in and rig up Cementers. Ensure pressure recorder is rigged in and serviceable. Pressure charts will be attached to the job ticket. Conduct a pre-job safety meeting to confirm volumes and procedures.

Establish circulation using pump truck. The casing and the hole will be filled with brine and circulated for 15 minutes to clean the borehole and to fill the casing and hole prior to cementing. Pressure test surface equipment to 14 MPa for 10 minutes. Preflush and mix water must be obtained from a clean source and the water trucks must be uncontaminated. Pump preflush of 3.0m³ of clean brine, with the addition of loss circulation material if necessary. Ensure that a minimum of 4 cement samples are taken and represent the cement at the beginning, middle and end of the cement job. Mix and pump sufficient Class 'G' 0-1-0 cement plus 10% NaCl, to cement the 114mm casing to surface plus 50% excess over open hole and 30% excess in cased hole. Drop wiper plug and displace cement with fresh water and bump plug to 3500 kPa over final pumping pressure - do not exceed 60% of internal yield pressure of casing. Once plug is bumped and it is determined that the float is holding, bleed casing pressure back to final pumping pressure, close casing valves and bleed off surface line pressure. Wash out BOPs and split BOP stack at 229mm flange, install 114mm slips and set slips in casing bowl. Wait on cement 24 hours and cut casing and remove BOPs. Cut and bevel 114mm casing and install primary and secondary seals. Install 229mm x 179mm spool piece and and test wellhead seals to 14 Mpa for 10 minutes. Install 179mm 14MPa x 21MPa double studded adapter and ANSI 900 Master Valve and shut-in well. 48 hours after cementing operations have been completed - pressure test casing, wellhead and master valve to 12,410kPa for a minimum of 4 hours - ensure that a digital pressure gauge is installed. Report results to the Enbridge Office - do not proceed with BOP installation until the pressure test has been successfully completed.

If the Master Valve is too high above the drill floor, the BOPs will be installed on the top of the spool piece and when the well is completed, a WR-1 plug will be set in the base of the casing and successfully pressure tested to 8300 kPa. The BOPs will then be removed and the Master Valve installed. Once the Master Valve has been installed and successfully pressure tested, the plug will be retrieved with a Wireline Service company.

Section 4.6 - Main Hole

1. Installation of the BOPs

Check cement samples for hardness – if cement samples are set to the satisfaction of the Wellsite Supervisor, proceed with installation of the BOPS. Install Class B (Rotary) BOPs as per MNR requirements. After BOPs and lubricator are installed and a minimum of 48 hours 'wait-on-cement-time' has passed and the cement samples indicate that the cement is competent, a cement bond log will be run on the 114mm casing. Consideration may be given to moving out the Rotary Rig and moving in a Cable Tool Rig. The Cable Tool Rig will install Class B (Cable Tool) BOPs.

2. Logging

Move in and rig up Wireline Company. With hole full of fresh water, run a Cement Bond Log, both a non-pressure and pressure pass. Run a Gamma-Ray / Neutron Log from TD to the base of the surface casing. Rig out Wireline Company and release.

3. Drilling Method

Each component of the BOPs and the casing will be pressure tested as per Section 6.2. Upon successful completion of the pressure testing of the BOPs, the cement, shoe and 0.5m of new formation will be drilled out and a PIT will be conducted, with the hole full of fresh water, using a bottom hole pressure equivalent to 18 kPa/m.

Drill a 98mm hole through the A-1 Carbonate and 1 metre into the A-1 Evaporite Formation — final TD will be determined by the Wellsite Geologist. While drilling the main hole ensure that drill cutting samples are taken every 3 metres and placed in the sample bags provided by the Ministry of Natural Resources. Record on daily tower sheets any influx of fluids and static levels (water and/or hydrocarbons), gas and any unusual hole conditions.

Drilling of the well may be suspended if sufficient permeability and porosity are encountered prior to reaching the proposed TD. If drilling is suspended, the rig will be moved off location and a variety of pressure tests will be performed on the well during withdrawal / injection operations. If the testing of the well shows that the porosity and permeability of the well are not suitable, a rig will be moved back onto location and the well will be drilled to the original TD-1 metre into the A-1 Evaporite.

4. Logging

Move in and rig up Wireline Company to run a Gamma-Ray/Neutron/Density Log over the open hole section of the well and run a Casing Inspection Log over the 114mm casing.

5. BOP Removal

Close master valve and nipple down BOPs and install 152mm (6") blind flange. If the master valve was not used for the drilling of the well — move in and rig up Wireline and Tool Companies and install a WR-1 plug in the base of the 114mm casing. Bleed down and fill the well with fresh water and pressure test the plug to 8300 kPa. Upon successful completion of the pressure test, remove BOPs and install master valve. Install a digital pressure recorder and pressure test casing, wellhead and master valve, with the hole full of fresh water to a surface pressure of 12,410kPa for a minimum of 4 hours. Report results to Enbridge Office. Do not rig down until well passes the pressure test. Move in Wireline Company to retrieve WR-1 plug.

6. Rig down rotary rig and move off of location and restore wellsite to Enbridge's specifications.

Section 4.7 - Loss Circulation Procedure

- 1. Before drilling out the casing shoe:
 - a. Identify sources and location of fresh water and/or brine, loss circulation materials and weight materials
 - b. Ensure BOPs and manifold are properly installed
 - c. Ensure auxiliary tanks are connected to the pumping system and a standby mud pump is hooked up for annular injection in case of severe loss circulation (so that fluid can be pumped down both the drill pipe and annulus simultaneously)
 - d. Pressure test BOPs prior to drill out

2. After drilling out shoe:

- a. Alert water suppliers and haulers
- b. Ensure adequate amounts of fresh water and/or brine are readily available prior to penetrating the Detroit River formation.
- Mechanically test BOPs and perform BOP drill prior to penetrating the Detroit River formation.

3. Drilling Blind - Detroit River formations:

- a. In an attempt to maintain or re-establish circulation, pump fluid down both the annulus and the drill pipe simultaneously
- b. Should severe loss circulation occur while drilling, the thief zone may be plugged with cement and/or loss circulation material at Enbridge's discretion.

Filed: 2012-02-15 EB-2012-0060 Attachment 3 Page 22 of 25

SECTION 5.0 - REPORTING PROCEDURES

Section 5.1 - Tower Sheets

Shall be completed daily and shall include:

- 1. Bit size, jars, depth at the beginning of the shift and end of each shift.
- 2. Casing size, grade, weight, and number of joints, centralizers, cement baskets, total length and setting depth.
- 3. Cementing information Service Company, cement type, amount, slurry density, additives, annular fluid returns, volume of displacement fluid and plug down time.
- 4. Water, gas or oil type, depth encountered depth of sample collected and the static level and/or rate of flow.
- 5. Pressure tests individually, surface pressures, fluid density used in the tests, bleed-off rate and duration of test.
- 6. Logging Details type and interval.
- 7. Abandonment details intervals, amount and type of cement, top of plug and time felt.
- 8. Rig release date and time.

Section 5.2 – Worker Injury

Every work related accident or injury shall be reported immediately to the Wellsite Supervisor. The Supervisor shall immediately contact the Ministry of Labour @ 1-800-265-5140 and the Ministry of Natural Resources @ 519-873-4634. The verbal report shall be followed with a written report as per the Occupational Health and Safety Act and the Oil, Gas & Salt Resources Act and Section 13 of the Operational Standards. The Supervisor will also be responsible for notifying the Operator (Enbridge Gas Distribution Inc.) and shall be responsible for the completion of Enbridge's Accident Report Form.

Filed: 2012-02-15 EB-2012-0060 Attachment 3 Page 23 of 25

SECTION 6.0 - SAFETY AND PROCEDURES

Section 6.1 - General Safety

- All works at the wellsite shall be in compliance with the Occupational Health and Safety Act and the Oil, Gas & Salt Resources Act and all associated legislation. In addition, all work at the wellsite shall be done in compliance with good oil field practices. All verbal notifications given to and approvals received from government agencies shall be recorded on the tower sheets.
- The Enbridge 'Job Safety Analysis Form' (JSA) shall be thoroughly reviewed by the Wellsite Supervisor with all onsite personnel through the daily safety meetings and any changes to the JSA will be noted on the Enbridge Safety Meeting / Tool Box Form.
- 3. Daily safety ('tailgate') meetings are to be conducted with each shift and recorded on the Enbridge Safety Meeting / Tool Box Form. Additional safety meetings are to be held with each crew, at the start of the well and safety meetings shall also be held prior to cementing and upon arrival of the logging company and prior to penetrating the Detroit River formations and the A-2 Carbonate formation.
- 4. The Wellsite Supervisor shall ensure that the operations are in compliance with all applicable government regulations and shall complete daily walk around rig inspections and record the results on their daily reports.

Section 6.2 – Well Control

All blowout prevention systems are to be in strict compliance with MNR regulations. The function and pressure testing guidelines required by the regulatory bodies (such as daily function testing of the pipe rams) will be strictly adhered to.

- 1. All pressure tests of blowout prevention equipment will be conducted with fresh water and will be conducted in 2 stages low and high pressure. It is essential that the low pressure test be done first, to prevent the high pressure test from healing leaks that would have been noted at low pressures.
- 2. The following pressure tests will be conducted with fresh water prior to drilling out each casing string and the results recorded on the tower sheets and daily reports:

Rotary:

- a. The blind rams, kill lines and choke manifold and casing will be tested individually for 10 minutes each to:
 - i. Intermediate casing 2000 kPa low & 9000 kPa high
 - ii. Production casing 2000 kPa low and 10000 kPa high

Filed: 2012-02-15 EB-2012-0060 Attachment 3 Page 24 of 25

- b. Run in hole with BHA, drill pipe and drill collars and pressure test the pipe rams, kelly cock, stand pipe, swivel, safety valves, etc. will be tested individually for 10 minutes each to:
 - i. Surface casing 1400 kPa low and 3500 kPa high (using AP)
 - ii. Intermediate casing 2000kPa low & 9000 kPa high
 - iii. Production casing 2000 kPa low and 10000 kPa high
- c. The annular preventer will be tested for 10 minutes to
 - i. Surface casing 1400 kPa low and 3500 kPa high
 - ii. Intermediate casing 2000 kPa low & 9000 kPa high
 - iii. Production casing 2000 kPa low and 10000 kPa high

Cable Tool:

- a. The blind rams, kill lines and casing will be tested individually for 10 minutes each to:
 - i. Intermediate casing 2000 kPa low & 8000 kPa high
 - ii. Production casing 2000 kPa low and 10000 kPa high
- b. Function test the pipe rams / shear rams, safety valves, etc. individually for 10 minutes each to:
 - i. Intermediate casing 2000kPa low & 8000 kPa high
 - ii. Production casing 2000 kPa low and 10000 kPa high
- c. The annular preventer will be tested for 10 minutes to
 - i. Surface casing 1400 kPa low and 3500 kPa high
 - ii. Intermediate casing 2000 kPa low & 8000 kPa high
 - iii. Production casing 2000 kPa low and 10000 kPa high
- d. The lubricator system will be tested for 10 minutes to
 - i. Production casing 2000 kPa low and 8000 kPa high
- e. A full lubricator system will be required when:
 - i. gas is encountered with H₂S content greater than 100ppm,
 - ii. when crude oil flows to surface or is capable of unloading during bailing operations, or
 - iii. when flows of natural gas exceed 7.0 10³m³/D (250Mcfd).
- 2. Upon drilling out the casing, drill 0.5m to 1.0m of new hole and test the formation, with the hole full of fresh water, to a minimum bottom hole pressure of 18 kPa per metre.
- 3. After one day of drilling below the casing shoe, check the entire blowout prevention system and tighten all bolts.

Filed: 2012-02-15 EB-2012-0060 Attachment 3 Page 25 of 25

- 4. Crews should be kept alert and familiar with the blowout prevention equipment. At least one member of the crew who has been trained in blowout prevention and well control procedures must be on the floor at all times.
- 5. Conduct blowout prevention drills prior to drilling out casing and once per week thereafter. Ensure that the drills are recorded in the tour book.
- 6. The blowout preventers are to be function tested once per tour. Ensure that the function test is recorded on the tower sheets.



Date of Birth

04.Apr.62

Company

Oil, Gas and Salt Resources Act

Filed: 2012-02-15 EB-2012-0060 Attachment 2 Page 1 of 25

v.2010-07-01

Application for a Well Licence

Form 1 To the Minister of Natural Resources
The undersigned operator applies for a well licence under the Oil, Gas and Salt Resources Act and the Regulations thereunder and submits


the followin	g Information,	together wi	th the appil	cation fee of \$	5100 + 13% HS	ST.						
1. WELL N	AME	TKC # 64 Moore 1-20-VI					Target Formation A-1 Carbonate					
Purpose of	Proposed We	li (Well Typ	e)			Ob	servation Well					
2. OPERA	TOR		Enbri	dge Gas Distr	ibution Inc.		Tel # 519-8	62-1473	Fax #	519-862-1168		
Street Addr	ess	3595 Tecumseh Road			Oh	Mooretown	Five O	N Postel Code	NON 1MO			
Mailing Add	lress	3595 Tecumseh Road			Giţ	Mooretown	seen O	N - Posta: Code	NON 1M0			
Contact Na	ntact Name Kathy McConnell						Contact Tel # 519-862-6032					
3. LOCATI	ON C	County Lambton To					Moore					
Tract	1 Lot _	20	Conce	ssion	VI	Lake Er	ie: <u> </u>	Tuci Li	osnoválevne tin			
Surface loca	ation, 1	50.90 m	North _	South	Latitude	42 ⁰ 50' 12	.525" Bot	tom-hole Lat.	42 ⁰ 5	0' 12.525"		
metres from Lot Boundar		295.2 n	n East	West	Longitu	de 82º 22' 5	7.714" Bot	tom-hole Long.	82°	22' 57.714"		
Within 1.6 k	um of Designat	ed Storage	-	Yes X	No□		Off-targe	t? Yes	No X			
	ARTICULARS		Vertical X	_	zontal	Directional	Deepening	_ Re-en		ateral		
Rig Type:	RotaryX	Cable	_	Well to be co		No[X]	Formation at T		A-1 Evapo			
Ground Elev			roposed De			psed Depth TVD		Proposed Start		15.Mar.12		
		<u>2.00</u> P	roposed De	:pui		osed Depail 14D	701.0	Tel #		10.19141, 12		
5. LANDOV												
Street Addre						Olky		Free	Postei Cr	23		
	ner herby provi ormation, via th					Landowner Sign	ature:	{Orig	inal Signed}			
has been co		Ont. Reg. 2	45/97 defir T.	itions for "poc	oled spacing ur	hed well location pla lt" and "unitize") Servicing / Bradco D	Yes	Tel# _5	19-695-6062 N Perbe Co	/ 519-689-4692 MOP 2C0 / NOP 1W0		
7. PROPOS	ED CASING	AND CEMI	ENTING P	ROGRAM	,			CASING	SETTING INF	OPMATION		
Hole Size	Casing O.D.	Weight	Grade	New, Used	Setting Depth TVD	Setting Fo	Setting Formation		Cement Type	Cement Top KB / RF		
(mm) 340	(mm) 340	(kg/m) 81.10	LS	New	42	Kettle	Point	Set Driven	nil	nll		
312	244	48.06	H40	New	57		Kettle Point		G	surface		
222	178	29,76	J55	New	385		F Shale		G	surface surface		
159	114	15.62	J55	New	660	A-2 Ani	nyarite	Cement		surrace		
B BLOW-O	UT PREVENT	ION FOLI	DMENT	9" 21	Annular Prev	entor						
6. DLOW-O	OTTALTEN	TOTA E QUI	MENT			Preventor and Dou	ble Gate					
9. WELL SE	CURITY N	ame of Trus	stee	Harrison	Pensa LLP	Total # U	Inplugged Wells		irrent Balance	\$70,000		
10. REMAR	KS											
11. ENCLO	SURES	Fee	X	Locat	ion Plan X	(Land wells only)		Drilling Progra	m X			
The Ministry o	n will be used fo	rces is colle r licensing a	nd law enfo	cement purpos	es only and will	uthority of the Oil, Gas be protected in accon Petroleum Resources Centro	dance with the Free	dom of Informat	on and Protect	ion of Privacy Act.		
13. AUTHO												
_	ned certifies the				s complete and	accurate, the opera	ator has the right	to drill or opera	te a well in the	above		
Date (d/m/y)	08.Feb	0.12	Name		J.E Sando	ers	Signature	{O	riginal Signed	}		

Enbridge Gas Distribution Inc.

Title

Director, Storage Operations

Filed: 2012-02-15 EB-2012-0060 Attachment 2 Page 2 of 25



Filed: 2012-02-15 EB-2012-0060 Attachment 2 Page 3 of 25

TKC # 64, Moore 2-20-VI

DRILLING PROGRAM

Filed: 2012-02-15 EB-2012-0060 Attachment 2 Page 4 of 25

TABLE OF CONTENTS

SECTION 1.0 GENERAL DATA

Section 1.1 Well Summary
Section 1.2 Special Notes

Section 1.3 Contact Numbers

SECTION 2.0 GEOLOGICAL PROGNOSIS

SECTION 3.0 CASING AND CEMENTING SUMMARY

Section 3.1 Summary
Section 3.2 Wellbore Diagram
Section 3.3 Wellhead Information

SECTION 4.0 DRILLING PROCEDURES

Section 4.1 Pre-Spud
Section 4.2 Conductor Casing
Section 4.3 Surface Hole and Surface Casing
Section 4.4 Intermediate Hole and Intermediate Casing
Section 4.5 Production Hole and Production Casing
Section 4.6 Main Hole
Section 4.7 Loss Circulation Procedure

SECTION 5.0 REPORTING PROCEDURES

Section 5.1 Tower Sheets Section 5.2 Worker Injury

SECTION 6.0 SAFETY AND PROCEDURES

Section 6.1 General Safety Section 6.2 Well Control

Filed: 2012-02-15 EB-2012-0060 Attachment 2 Page 5 of 25

SECTION 1.0 - GENERAL DATA

Section 1.1 - Well Summary

Well Name:

TKC # 64 Moore 2-20-VI

Operator:

Enbridge Gas Distribution Inc.

Surface Location:

Tract 2, Lot 20, Con. 6, Moore Twp, Lambton County

Surface Coordinates:

159.90m South; 295.2m West

Ground Elevation:

192.60m

KB Elevation:

193.90m

Total Depth:

701m

Target Formation:

A-1 Carbonate

Logging Program:

Gamma Ray / Neutron from TD to base of Surface Casing

Porosity / Density Log A-2 Anhydrite to TD

CBL-GR – 114mm casing Vertilog – 114mm casing

Spud Date:

March 15th, 2012

Duration:

45 days

Section 1.2 - Special Notes

1. Safety of personnel and environment is our primary concern. Section 6.1 of this program, outlines Enbridge's general safety requirements which obliges all personnel on the wellsite to follow the Occupational Health and Safety Act and Regulations (Ministry of Labour) and the Oil, Gas & Salt Resources Act and Regulations (Ministry of Natural Resources). Safety and/or environmental ("tailgate") meetings shall be conducted as per Section 6. Wellsite Supervisor shall conduct daily 'walk around' inspections of the equipment on site and record the results on the daily reports. Please refer to Section 5.2 for the procedure to be followed if a worker injury occurs.

 The Wellsite Supervisor has authority over all activities conducted on the drilling location. The Wellsite Supervisor shall ensure that all applicable regulations and policies (MNR, MOL, MOEE, and Enbridge) are followed and that all permits are kept on site and/or signed off as required.

Filed: 2012-02-15 EB-2012-0060 Attachment 2 Page 6 of 25

- 3. All operations are to be to MNR standards.
- 4. BOPs are to be installed, maintained and used as per MNR requirements. Testing of the BOPs must be in accordance with Section 6.2 of this program.
- 5. Tower sheets must be completed daily and will include the information listed in Section 5.1 of this program. The Wellsite Supervisor will complete daily reports and forward the reports to Enbridge's office by 10am the following day.
- 6. The production casing will be set in the A-2 Anhydrite to allow for an effective cement job and successful pressure testing, prior to penetrating the A-1 Carbonate formation.

Section 1.3 - Contact Numbers

Enbridge Gas Distribution Inc.

Kathy McConnell Senior Project Geologist Office: 519-862-6032

Fax: 519-862-1168 Cell: 519-312-2168

kathy.mcconnell@enbridge.com

Paul Druet Manager, Reservoir Office: 519-862-6016

> 519-862-1168 Development Fax: 519-383-4012 Cell:

paul.druet@enbridge.com

Terry Chupa Land Administrator Office: 519-862-6008 Fax: 519-862-1168

Cell: 519-384-0215 terry.chupa@enbridge.com

Office: 519-862-6012 Control Room

Drilling Supervisor:

Cell: 519-383-5404 Steve Thompson

omniconsulting@rogers.com

Cell: 519-312-8437 Wayne Bolton

kegconsulting@aim.com

Filed: 2012-02-15 EB-2012-0060 Attachment 2 Page 7 of 25

Geologist:

Neil Hoey Office: 519-472-4776

Fax: 519-472-4776 Cell: 519-649-6918 neil_hoey@hotmail.com

Cable Tool Rig - Terry Marsh Well Drilling & Servicing

Terry Marsh Owner / Operator Office: 519-695-6060

Fax: 519-695-6464 Cell: 519-359-9804 twmarshca@yahoo.com

Rotary Rig - Bradco Drilling Inc.

Brad Stevenson Owner / Operator Office: 519-689-4692

Fax: 519-689-7516 Cell: 519-358-3742 bradco@ciaccess.com

Cementing

Ian Veen Black Creek Well Service Office: 519-882-4732

President 519-834-2941

Fax: 519-834-2466 Cell: 519-686-4645

Jay Rookes Schlumberger Canada Office: 519-652-5053

Engineer-In-Charge Fax: 519-652-6002

rookes1@slb.com

Casing & Wellheads – Wellmaster Pipe & Supply Inc.

Andy Arnoczki Sales Representative Office: 519-688-0500

Fax: 519-688-0563 Cell: 519-537-0559 aarnoczki@wellmaster.ca

Bill Hedges Inside Sales Office: 519-688-0500

Fax: 519-688-0563 bhedges@wellmaster.ca

Graham Shone Operations Manager Office: 519-336-9797

Fax: 519-336-9733 Cell: 519-331-2534 gshone@cefranklin.com

Larry Rushton Owner Office: 519-326-8884 Fax: 519-326-8882 rushtonsupply@sympatico.ca Wireline Services Gord MacKenzie Baker Atlas Office: 519-332-8030 Base Manager Fax: 519-332-4714 Cell: 519-339-6783 gord.mackenzie@bakerhughes.com **Dave Tipping** Weatherford Canada -Office: 519-683-2010 Wireline & Logging Fax: 519-683-2577 Services Cell: 519-436-3541 Station Manager dave.tipping@canada.weatherford.com **Snubbing Services** Derrick Jacobson President Office: 877-829-7242 Quattro Energy Services Fax: 403-720-6319 Inc. Cell: 403-828-7242 derrick@quattroenergy.ca Jeff Redmond **Team Snubbing Services** Office: 403-314-4220 403-844-2148 Inc. Fax: 403-896-8363 Cell: jredmond@teamsnubbing.com Water Hauling Office: 519-864-1037 Melvin McKeegan President McKeegan Trucking Fax: 519-864-1036 Limited Cell: 519-490-4028 Denis Marcus President Office: 519-695-3735 Harold Marcus Limited Fax: 519-695-2249 Cell: 519-380-5238 dmarcus@haroldmarcus.com President Office: 519-676-6747 Aaron Verstraete Oil Patch Services 519-676-7932 Fax: Cell: 519-380-5473 ops.aaron@bellnet.ca Rental Equipment

Wheatley Wireline Services

Ltd.

Derrick Holland

Office: 519-825-3680

519-825-9348 519-322-8439

dholland891@hotmail.com

Fax:

Cell:

Filed: 2012-02-15 EB-2012-0060 Attachment 2 Page 9 of 25

Wade Glass Wheatley Wireline Services Office: 519-825-3680 Ltd. Fax: 519-825-9348 Cell: 519-322-9275 Orval Beam Orval L. Beam Limited Office: 519-436-0164 Operations Manager Fax: 519-436-0164 Tank Rentals Cell: 519-436-4801 Jim Seward JW Seward Enterprises Ltd Office: 519-867-5526 Crane Trucks, Steel Plates Fax: 519-867-5312 Cell: 519-332-7689 Welders - St. Clair Mechanical John Dawson President Office: 519-864-0927 Fax: 519-864-0801 Cell: 519-330-9672 Government & Other Agencies **MNR** Petroleum Resources Centre Office: 519-873-4634 Fax: 519-873-4645 ogsr.mnr.gov.on.ca Spill Reporting **MOEE** 1-800-268-6060 MOL Health & Safety 1-800-265-1676 Health & Safety Inspector Office: 519-646-3238

Oil, Gas & Salt Resources

Library

Police, Fire &

Richard Ostrowski

Ambulance

Fax:

Fax:

519-672-0268

519-686-7225

Office: 519-686-2772

richard@ogsrlibrary.com

Filed: 2012-02-15 EB-2012-0060 Attachment 2 Page 10 of 25

SECTION 2.0 **GEOLOGICAL PROGNOSIS**

County: Lambton Township: Moore

Concession: VI Lot: 20 Tract: 2

Elevation: 192.9m **Estimated**

Formation	Тор	Elevation	Thickness	Gas	Oil	Water
K.B.	0.0	194.4	1.5			
Drift	1.5	192.9	40.5			
Kettle Point	42.0	152.4	29.3			
Hamilton	71.3	123.1	77.7			
Dundee	149.0	45.4	34.2			
Lucas	183.2	11.2	151.8			Sulphur@188m
Amherstburg	0.0	0.0	0.0			
Bois Blanc	0.0	0.0	0.0			
Bass Islands	333.8	-140.6	41.1			
G-Shale	374.9	-181.7	5.2			
F-Shale	380.1	-186.9	48.1			
F-Salt	428.2	-235.0	13.8			
E-Carbonate	442.0	-248.8	27.7			
D-Salt	469.7	-276.5	6.4			
C-Shale	476.1	-282.9	42.1			
B-Salt	518.2	-324.9	68.0			
A-2 Carbonate	586.1	-392.9	47.0			
A-2 Salt	633.1	-439.9	25.6			
A-2 Anhydrite	658.7	-465.4	2.1			
A-1 Carbonate	660.8	-467.6	39.0	661; 665;	670	
A-1 Evaporite	699.8	-506.6	4.0	667	670	
TD	700.8	-507.6	0.0			

^{***}Note: Prognosis with TVD tops.
***Note: used Kimball No.21 to build prog


SECTION 3.0 - CASING AND CEMENTING SUMMARY

Section 3.1 - Summary

Hole Size (mm)	Casing Size (mm)	Casing Grade	Casing Weight (kg/m)	Setting Depth (mKB)	How Set
340	340	LS	81.10	42	Driven – cement squeeze if necessary
312	244	H40	48.06	57	Cemented to surface with 100% excess Class G 0-1-0 cement + 2 - 3% CaCl ₂
222	178	J55	29.76	385	Cemented to surface with Class 'G' 0-1-8% plus 1 to 3% CaCl ₂ , followed by Class 'G' neat cement plus 1 to 3% CaCl ₂ . Cement volumes will be calculated with a 50% excess- gel cement and 30% excess – neat cement. Depending upon hole conditions, consideration may be given to running thixotropic cement plus additional loss circulation materials, across porous zone(s).
159	114	J55	15.62	660	Cemented to surface with Class 'G' 0-1-0% plus 1 to 2% CaCl ₂ plus 10% NaCl. Cement volumes will be calculated with a 50% excess on the open hole section and 30% excess on the cased hole section.

Main Hole: 98mm open hole will be drilled from 660m to 701m

Section 3.2 - Wellbore Diagram




Filed: 2012-02-15 EB-2012-0060 Attachment 2 Page 13 of 25

Section 3.3 - Wellhead Summary

Weatherford 13.8 MPa Wellhead:

244mm x 279mm slip on weld on casing bowl for BOP installation 178mm x 229mm slip on weld on casing bowl 229mm x 179mm spool c/w 2 gate valves on side outlets 179mm 13.MPa x 179mm x 20.7 MPa double studded adapter 152mm ANSI 900 Cameron Grove full port ball valve



Filed: 2012-02-15 EB-2012-0060 Attachment 2 Page 14 of 25

SECTION 4.0 - DRILLING PROCEDURES

Section 4.1 - Pre Spud

Fresh Water Well Samples

Obtain samples from all fresh water wells located within a 750 metre radius of the proposed well. Have routine water analysis done on all water samples by an independent laboratory in Sarnia. Ensure that copies of these reports are placed in the well files in Enbridge's office

2. Site Preparation

Prepare drilling location as follows:

- a. Locate all drainage tiles crossing lease area
- b. Strip and properly stock pile all soil from the lease
- c. Cut, block and divert drainage tiles as required
- d. Construct adequate berms around lease and access road as required

3. Government Notification of Spud

48 hours prior to spud, notify the Ministry of Natural Resources – Petroleum Resources Section by fax @ (519) 873 – 4645 of the date of commencement of drilling operations

4. Signs

Install rig signs on access road to lease.

5. Safety Meeting

Conduct a pre-spud safety meeting for Rig crews. Tool push and all crewmembers must be present. A similar meeting shall be conducted with the remaining crew(s) as they come on duty. Additional safety meetings shall be conducted as per Section 6.1 of this program.

Section 4.2 - Conductor Casing

1. Drilling Method

Move in and rig up Cable Tool Rig. Measure and record the distance from RF to ground and the RF elevation – include these measurements on the tower sheets and the daily report. Drill and drive 340mm casing to bedrock, to an approximate depth of 42m. Note any occurrence of water and record type of water, depth encountered, and static level of water and/or flow rate. If fresh water is encountered during

drilling, the well must be bail tested for at least 15 minutes, after the casing is landed, to ensure that the fresh water has been shut-off. If the fresh water has not been shut-off, contact Enbridge's office and be prepared to perform a cement squeeze as per Enbridge's requirements.

2. Cement Squeeze (if necessary)

If fresh water is found in the drift and is not shut-off by the conductor casing, a flow rate will be established and a cement squeeze will be performed, using the cement volumes determined by Enbridge. Wait on cement 12 hours and bail the hole dry and monitor the well for at least 15 minutes to determine if the water has been shut-off. If necessary, the process will be repeated until the water is shut-off.

Section 4.3 - Surface Hole & Surface Casing

1. Drilling Method

Drill a 312mm hole 15 metres \pm into the Kettle Point formation, to an approximate depth of 57m. Ensure that drill cutting samples are taken every 3 metres and placed in the sample bags provided by the Ministry of Natural Resources. The sample bags must be labeled with the well name, Township, Lot, Concession and Enbridge's name. Record on daily drilling reports any influx of fluids and/or hydrocarbons, static levels, pressures and any unusual hole conditions.

2. Casing Installation

Depending upon hole conditions encountered, the 244mm casing will be run in the following manner:

- · Texas Shoe on bottom of first joint
- Centralizers on the top and bottom of the first joint and coincident with the shoe of the conductor casing
- 244mm casing to surface

3. Cementing Procedures

Move in and rig up Cementers. Ensure pressure recorder is rigged in and serviceable. Pressure charts will be attached to the job ticket. Conduct a pre-job safety meeting to confirm volumes and procedures. Establish circulation using pump truck. The casing and the hole will be circulated with fresh water for 15 minutes to clean the borehole and to fill the casing and hole prior to cementing. Pressure test surface equipment to 14 MPa. Ensure that preflush and mix water are from a clean source and that the water trucks are uncontaminated. Pump preflush of 2.0m^3 of fresh water, with the addition of loss circulation material if necessary. Ensure that a minimum of 4 cement samples are taken and represent the cement at the beginning, middle and end of the cement job. Mix and pump sufficient Class 'G' 0-1-0% cement plus 2 to 3% CaCl₂

with a density of 1901 kg/m³ to cement the casing to surface with 100% excess. Displace cement with fresh water – ensure that cement is under displaced and that the bottom joint of casing is full of cement. Shut-in cementing valve at surface and wait on cement at least 12 hours before slacking off casing.

- 4. Install 244mm x 279mm slip on weld on casing bowl for BOP installation. Arrange to have surface hole cuttings solidified and then disposed in an approved manner.
- 5. Release the Cable Tool Rig.

Section 4.4 - Intermediate Hole & Intermediate Casing

1. BOP Installation and Pressure Testing

Move in and rig up Rotary Rig. Measure and record the distance from KB to ground and the KB elevation – include these measurements on the tower sheets and the daily report.

Install Class A (Rotary) BOPs as per MNR requirements. After BOPs are installed and the cement samples indicate that the cement is competent, the rig will proceed to pressure test the BOPs, casing and shoe. Pressure test casing and each component of the BOPs as per Section 6.2. After successfully pressure testing the BOPs and casing, drill out cement and 0.5m of new formation and conduct a PIT, with the hole full of fresh water, using a bottom hole pressure equivalent to 18 kPa/m.

2. Drilling Method

Drill a 222mm hole with fresh water to $5m \pm into$ the F Shale formation, to an approximate depth of 385m. Notify Geologist 12 hours in advance of reaching intermediate casing point, so that they can be on site to determine the proper casing setting depth. When casing setting depth has been determined, circulated the hole clean. Perform a flow check prior to tripping and strap out of the hole. Fast tripping of the drill string is to be avoided in order to eliminate high annular velocities, pressure surges and swabbing (maximum rate of 27 metres per minute). Keeping the hole full of fluid, trip out of the hole and laydown bottom hole assembly and depending upon rotary rig type, standback or laydown drill collars and drill pipe.

The potential for loss circulation exists while drilling through the Detroit River formations (Lucas and Amherstburg formations). If loss circulation is encountered use the loss circulation contingency program located in Section 4.7. Note all lost circulation intervals and monitor and record fluid loss volumes. If pit fluid must be hauled to disposal, keep solid content to a minimum to reduce costs.

Ensure that drill cutting samples are taken every 3 metres and placed in the sample bags provided by the Ministry of Natural Resources. Record on daily tower sheets

Filed: 2012-02-15 EB-2012-0060 Attachment 2 Page 17 of 25

any influx of fluids and static levels (water and/or hydrocarbons), gas and/or any unusual hole conditions.

3. Casing Installation

Ensure that the threads are protected while hoisting casing to the floor. Drift all casing prior to running the casing in the well and apply proper API make-up torque to each connection.

Depending upon hole conditions encountered, the 178mm casing will be run in the following manner:

- Guide shoe
- 178mm joint of casing
- 178mm Float Insert or Float Collar
- Tack weld guide shoe, float collar and bottom 2 joints and use API modified pipe dope on all connections
- Centralizers will be installed one metre above the guide shoe, over the bottom of the first 2 collars and every 5 joints to surface
- 178mm casing to surface

4. Cementing Procedures

Move in and rig up Cementers. Ensure pressure recorder is rigged in and serviceable. Pressure charts will be attached to the job ticket. Conduct a pre-job safety meeting to confirm volumes and procedures. Fill hole and establish circulation using pump truck. The casing and the hole will be circulated with fresh water for 15 minutes to clean the borehole and to fill the casing and hole prior to cementing. Pressure test surface equipment to 14MPa for 10 minutes. Preflush and mix water must be obtained from a clean source and the water trucks must be uncontaminated. Pump preflush of 3.0m3 of fresh water, with the addition of loss circulation material if necessary. Ensure that a minimum of 4 cement samples are taken and represent the cement at the beginning, middle and end of the cement job. Mix and pump sufficient 0-1-8 Class 'G' cement plus 1 to 3% CaCl₂ (50% excess) followed by 0-1-0 Class 'G' cement plus 1 to 3% CaCl₂ (30% excess) to cement casing to surface. Depending upon the severity of the loss circulation zones, thixotropic cement with additional loss circulation materials may be used to cover the loss zone. If there are no cement returns to surface, a feed rate will be established and the annulus will be grouted to surface. Drop wiper plug and displace cement and bump plug to 3.5 Mpa over final pumping pressure - do not exceed 60% of internal yield pressure of casing. Once plug is bumped and it is determined that the float is holding, bleed casing pressure back to final pumping pressure, close casing valves and bleed off surface line pressure and wash out BOPs. Wait on cement 24 hours before slacking off casing. Remove 244mm x 279mm casing bowl and install 178mm x 229mm casing bowl on the 178mm casing.

Section 4.5 - Production Hole & Production Casing

1. Pressure Testing

Check cement samples for hardness – if cement samples are set to the satisfaction of the Wellsite Supervisor, proceed with installation of the BOPS. Install Class B (Rotary) BOPs as per MNR requirements on 178mm casing bowl. After BOPs are installed and the cement samples indicate that the cement is competent, the rig will proceed to pressure test the BOPs, casing and shoe. Pressure test casing and each component of the BOPs as per Section 6.2. After successfully pressure testing the BOPs and casing, drill out cement and 0.5m of new formation and conduct a PIT, with the hole full of fresh water, using a bottom hole pressure equivalent to 18 kPa/m.

2. Drilling Method

Drill a 159mm hole using brine to prevent the dissolution of the salt layers. Ensure that drill cutting samples are taken every 3 metres and placed in the sample bags provided by the Ministry of Natural Resources. Record on daily tower sheets any influx of fluids and static levels (water and/or hydrocarbons), gas and any unusual hole conditions.

Prior to penetrating the A-2 Carbonate, the Wellsite Geologist and Wellsite Supervisor must be on-site and a BOP drill shall be completed to familiarize all onsite personnel with the proper procedures.

Drill a 159mm hole $1 \pm$ metres into the A-2 Anhydrite formation, to an approximate depth of 660m. The final casing point will be determined by the Wellsite Geologist.

If the reef pressure is above 7000kPa, drilling will be suspended and the rig will be moved off location after the 114mm casing is installed and cemented. The rig will be brought back onto location to complete the drilling of the well when the reef pressure is below 7000kPa.

3. Casing Installation

Ensure that the threads are protected while hoisting casing to the floor. Drift all casing prior to running the casing in the well and apply proper API make-up torque to each connection.

Depending upon hole conditions encountered, the 114mm casing will be run in the following manner:

- Guide shoe
- 114mm joint of casing
- Float Insert or Float Collar
- Tack weld guide shoe, float collar and bottom 4 joints and use API modified pipe dope on all connections

Filed: 2012-02-15 EB-2012-0060 Attachment 2 Page 19 of 25

- Centralizers will be installed on bottom 5 joints of casing on every 5th joint to surface
- 114mm casing to surface

4. Cementing Procedures

Move in and rig up Cementers. Ensure pressure recorder is rigged in and serviceable. Pressure charts will be attached to the job ticket. Conduct a pre-job safety meeting to confirm volumes and procedures.

Establish circulation using pump truck. The casing and the hole will be filled with brine and circulated for 15 minutes to clean the borehole and to fill the casing and hole prior to cementing. Pressure test surface equipment to 14 MPa for 10 minutes. Preflush and mix water must be obtained from a clean source and the water trucks must be uncontaminated. Pump preflush of 3.0m³ of clean brine, with the addition of loss circulation material if necessary. Ensure that a minimum of 4 cement samples are taken and represent the cement at the beginning, middle and end of the cement job. Mix and pump sufficient Class 'G' 0-1-0 cement plus 10% NaCl, to cement the 114mm casing to surface plus 50% excess over open hole and 30% excess in cased hole. Drop wiper plug and displace cement with fresh water and bump plug to 3500 kPa over final pumping pressure – do not exceed 60% of internal yield pressure of casing. Once plug is bumped and it is determined that the float is holding, bleed casing pressure back to final pumping pressure, close casing valves and bleed off surface line pressure. Wash out BOPs and split BOP stack at 229mm flange, install 114mm slips and set slips in casing bowl. Wait on cement 24 hours and cut casing and remove BOPs. Cut and bevel 114mm casing and install primary and secondary seals. Install 229mm x 179mm spool piece and and test wellhead seals to 14 Mpa for 10 minutes. Install 179mm 14MPa x 21MPa double studded adapter and ANSI 900 Master Valve and shut-in well. 48 hours after cementing operations have been completed - pressure test casing, wellhead and master valve to 12,410kPa for a minimum of 4 hours - ensure that a digital pressure gauge is installed. Report results to the Enbridge Office - do not proceed with BOP installation until the pressure test has been successfully completed.

If the Master Valve is too high above the drill floor, the BOPs will be installed on the top of the spool piece and when the well is completed, a WR-1 plug will be set in the base of the casing and successfully pressure tested to 8300 kPa. The BOPs will then be removed and the Master Valve installed. Once the Master Valve has been installed and successfully pressure tested, the plug will be retrieved with a Wireline Service company.

Section 4.6 - Main Hole

1. Installation of the BOPs

Check cement samples for hardness – if cement samples are set to the satisfaction of the Wellsite Supervisor, proceed with installation of the BOPS. Install Class B

(Rotary) BOPs as per MNR requirements. After BOPs and lubricator are installed and a minimum of 48 hours 'wait-on-cement-time' has passed and the cement samples indicate that the cement is competent, a cement bond log will be run on the 114mm casing. Consideration may be given to moving out the Rotary Rig and moving in a Cable Tool Rig. The Cable Tool Rig will install Class B (Cable Tool) BOPs.

2. Logging

Move in and rig up Wireline Company. With hole full of fresh water, run a Cement Bond Log, both a non-pressure and pressure pass. Run a Gamma-Ray / Neutron Log from TD to the base of the surface casing. Rig out Wireline Company and release.

3. Drilling Method

Each component of the BOPs and the casing will be pressure tested as per Section 6.2. Upon successful completion of the pressure testing of the BOPs, the cement, shoe and 0.5m of new formation will be drilled out and a PIT will be conducted, with the hole full of fresh water, using a bottom hole pressure equivalent to 18 kPa/m.

Drill a 98mm hole through the A-1 Carbonate and 1 metre into the A-1 Evaporite Formation – final TD will be determined by the Wellsite Geologist. While drilling the main hole ensure that drill cutting samples are taken every 3 metres and placed in the sample bags provided by the Ministry of Natural Resources. Record on daily tower sheets any influx of fluids and static levels (water and/or hydrocarbons), gas and any unusual hole conditions.

Drilling of the well may be suspended if sufficient permeability and porosity are encountered prior to reaching the proposed TD. If drilling is suspended, the rig will be moved off location and a variety of pressure tests will be performed on the well during withdrawal / injection operations. If the testing of the well shows that the porosity and permeability of the well are not suitable, a rig will be moved back onto location and the well will be drilled to the original TD-1 metre into the A-1 Evaporite.

4. Logging

Move in and rig up Wireline Company to run a Gamma-Ray/Neutron/Density Log over the open hole section of the well and run a Casing Inspection Log over the 114mm casing.

5. BOP Removal

Close master valve and nipple down BOPs and install 152mm (6") blind flange. If the master valve was not used for the drilling of the well — move in and rig up Wireline and Tool Companies and install a WR-1 plug in the base of the 114mm casing. Bleed down and fill the well with fresh water and pressure test the plug to

Filed: 2012-02-15 EB-2012-0060 Attachment 2 Page 21 of 25

8300 kPa. Upon successful completion of the pressure test, remove BOPs and install master valve. Install a digital pressure recorder and pressure test casing, wellhead and master valve, with the hole full of fresh water to a surface pressure of 12,410kPa for a minimum of 4 hours. Report results to Enbridge Office. Do not rig down until well passes the pressure test. Move in Wireline Company to retrieve WR-1 plug.

- 6. Rig down rotary rig and move off of location.
- 7. Restore wellsite to Enbridge's specifications.

Section 4.7 - Loss Circulation Procedure

- 1. Before drilling out the casing shoe:
 - a. Identify sources and location of fresh water and/or brine, loss circulation materials and weight materials
 - b. Ensure BOPs and manifold are properly installed
 - c. Ensure auxiliary tanks are connected to the pumping system and a standby mud pump is hooked up for annular injection in case of severe loss circulation (so that fluid can be pumped down both the drill pipe and annulus simultaneously)
 - d. Pressure test BOPs prior to drill out
- 2. After drilling out shoe:
 - a. Alert water suppliers and haulers
 - b. Ensure adequate amounts of fresh water and/or brine are readily available prior to penetrating the Detroit River formation.
 - c. Mechanically test BOPs and perform BOP drill prior to penetrating the Detroit River formation.
- 3. Drilling Blind Detroit River formations:
 - a. In an attempt to maintain or re-establish circulation, pump fluid down both the annulus and the drill pipe simultaneously
 - b. Should severe loss circulation occur while drilling, the thief zone may be plugged with cement and/or loss circulation material at Enbridge's discretion.

Filed: 2012-02-15 EB-2012-0060 Attachment 2 Page 22 of 25

SECTION 5.0 - REPORTING PROCEDURES

Section 5.1 - Tower Sheets

Shall be completed daily and shall include:

- 1. Bit size, jars, depth at the beginning of the shift and end of each shift.
- 2. Casing size, grade, weight, and number of joints, centralizers, cement baskets, total length and setting depth.
- 3. Cementing information Service Company, cement type, amount, slurry density, additives, annular fluid returns, volume of displacement fluid and plug down time.
- 4. Water, gas or oil type, depth encountered depth of sample collected and the static level and/or rate of flow.
- 5. Pressure tests individually, surface pressures, fluid density used in the tests, bleed-off rate and duration of test.
- 6. Logging Details type and interval.
- 7. Abandonment details intervals, amount and type of cement, top of plug and time felt.
- 8. Rig release date and time.

Section 5.2 - Worker Injury

Every work related accident or injury shall be reported immediately to the Wellsite Supervisor. The Supervisor shall immediately contact the Ministry of Labour @ 1-800-265-5140 and the Ministry of Natural Resources @ 519-873-4634. The verbal report shall be followed with a written report as per the Occupational Health and Safety Act and the Oil, Gas & Salt Resources Act and Section 13 of the Operational Standards. The Supervisor will also be responsible for notifying the Operator (Enbridge Gas Distribution Inc.) and shall be responsible for the completion of Enbridge's Accident Report Form.

Filed: 2012-02-15 EB-2012-0060 Attachment 2 Page 23 of 25

SECTION 6.0 - SAFETY AND PROCEDURES

Section 6.1 - General Safety

- All works at the wellsite shall be in compliance with the Occupational Health and Safety Act and the Oil, Gas & Salt Resources Act and all associated legislation. In addition, all work at the wellsite shall be done in compliance with good oil field practices. All verbal notifications given to and approvals received from government agencies shall be recorded on the tower sheets.
- The Enbridge 'Job Safety Analysis Form' (JSA) shall be thoroughly reviewed by the Wellsite Supervisor with all onsite personnel through the daily safety meetings and any changes to the JSA will be noted on the Enbridge Safety Meeting / Tool Box Form.
- 3. Daily safety ('tailgate') meetings are to be conducted with each shift and recorded on the Enbridge Safety Meeting / Tool Box Form. Additional safety meetings are to be held with each crew, at the start of the well and safety meetings shall also be held prior to cementing and upon arrival of the logging company and prior to penetrating the Detroit River formations and the A-2 Carbonate formation.
- 4. The Wellsite Supervisor shall ensure that the operations are in compliance with all applicable government regulations and shall complete daily walk around rig inspections and record the results on their daily reports.

Section 6.2 - Well Control

All blowout prevention systems are to be in strict compliance with MNR regulations. The function and pressure testing guidelines required by the regulatory bodies (such as daily function testing of the pipe rams) will be strictly adhered to.

- 1. All pressure tests of blowout prevention equipment will be conducted with fresh water and will be conducted in 2 stages low and high pressure. It is essential that the low pressure test be done first, to prevent the high pressure test from healing leaks that would have been noted at low pressures.
- 2. The following pressure tests will be conducted with fresh water prior to drilling out each casing string and the results recorded on the tower sheets and daily reports:

Rotary:

- a. The blind rams, kill lines and choke manifold and casing will be tested individually for 10 minutes each to:
 - i. Intermediate casing 2000 kPa low & 9000 kPa high
 - ii. Production casing 2000 kPa low and 10000 kPa high

Filed: 2012-02-15 EB-2012-0060 Attachment 2 Page 24 of 25

- b. Run in hole with BHA, drill pipe and drill collars and pressure test the pipe rams, kelly cock, stand pipe, swivel, safety valves, etc. will be tested individually for 10 minutes each to:
 - i. Surface casing 1400 kPa low and 3500 kPa high (using AP)
 - ii. Intermediate casing 2000kPa low & 9000 kPa high
 - iii. Production casing 2000 kPa low and 10000 kPa high
- c. The annular preventer will be tested for 10 minutes to
 - i. Surface casing 1400 kPa low and 3500 kPa high
 - ii. Intermediate casing 2000 kPa low & 9000 kPa high
 - iii. Production casing 2000 kPa low and 10000 kPa high

Cable Tool:

- a. The blind rams, kill lines and casing will be tested individually for 10 minutes each to:
 - i. Intermediate casing 2000 kPa low & 8000 kPa high
 - ii. Production casing 2000 kPa low and 10000 kPa high
- b. Function test the pipe rams / shear rams, safety valves, etc. individually for 10 minutes each to:
 - i. Intermediate casing 2000kPa low & 8000 kPa high
 - ii. Production casing 2000 kPa low and 10000 kPa high
- c. The annular preventer will be tested for 10 minutes to
 - i. Surface casing 1400 kPa low and 3500 kPa high
 - ii. Intermediate casing 2000 kPa low & 8000 kPa high
 - iii. Production casing 2000 kPa low and 10000 kPa high
- d. The lubricator system will be tested for 10 minutes to
 - i. Production casing 2000 kPa low and 8000 kPa high
- e. A full lubricator system will be required when:
 - i. gas is encountered with H2S content greater than 100ppm,
 - ii. when crude oil flows to surface or is capable of unloading during bailing operations, or
 - iii. when flows of natural gas exceed 7.0 10³m³/D (250Mcfd).
- 2. Upon drilling out the casing, drill 0.5m to 1.0m of new hole and test the formation, with the hole full of fresh water, to a minimum bottom hole pressure of 18 kPa per metre.
- 3. After one day of drilling below the casing shoe, check the entire blowout prevention system and tighten all bolts.

Filed: 2012-02-15 EB-2012-0060 Attachment 2 Page 25 of 25

- 4. Crews should be kept alert and familiar with the blowout prevention equipment. At least one member of the crew who has been trained in blowout prevention and well control procedures must be on the floor at all times.
- 5. Conduct blowout prevention drills prior to drilling out casing and once per week thereafter. Ensure that the drills are recorded in the tour book.
- 6. The blowout preventers are to be function tested once per tour. Ensure that the function test is recorded on the tower sheets.



Oil, Gas and Salt Resources Act

Application for a Well Licence

Filed: 2012-02-15 EB-2012-0060 Attachment 1

Page 1 of 25 To the Minister of Natural Resources v.2010-07-01 Form 1 The undersigned operator applies for a well licence under the Oil, Gas and Salt Resources Act and the Regulations thereunder and submits the following information, together with the application fee of \$100 + 13% HST. TKC # 63 Moore 6-18-VIII Target Formation A-1 Carbonate 1. WELL NAME Observation Well Purpose of Proposed Well (Well Type) Enbridge Gas Distribution Inc. Tel # 519-862-1473 Fax# 519-862-1168 2. OPERATOR N0N 1M0 ON Postel Code Street Address 3595 Tecumseh Road Mooretown Store. Oily NON 1M0 3595 Tecumseh Road Mooretown ON Postar Code Oky Mailing Address Contact Tel # Kathy McConnell 519-862-6032 Contact Name Moore Township 3. LOCATION County Lambton VIII Yeard 18 Concession Lake Erie: & look Licence Leane No. Bottom-hole Lat. 42°51'16.722" 495.0 m North X South 42*51'16.722" Latitude Surface location. metres from 82°22'10.021" West Bottom-hole Long. 82°22'10.021" 110,1 m East X Longitude Lot Boundaries Yes NoX Off-target? Within 1.6 km of Designated Storage Area? YesX No Deepening Directional Re-entry Lateral Vertical X Horizontal 4. WELL PARTICULARS Formation at TD Cable X Yes NoX A-1 Evaporite Rotary X Well to be cored? Rig Type: 194.5 Proposed Depth 740.0 Proposed Depth TVD 740.00 Proposed Start Date Ground Elevation 5. LANDOWNER Tel# Mooretown ON Physial Code Street Address The landowner herby provides consent for the collection of their (Original Signed) personal information, via the operator, as per Section 12 of this form. Landowner Signature: Pooling of the Spacing Unit or unitization of the Unit Area shown on the attached well location plan YesX No has been completed (see Ont. Reg. 245/97 definitions for "pooled spacing unit" and "unitize") Tel# 519-695-6060 / 519-689-4692 T.W. Marsh Well Drilling and Servicing / Bradco Drilling Inc. 6. DRILLING CONTRACTOR Petta: Cota NOP 2C0 / Bothwell / Merlin ON Box 53 / 14 Hattie St., Box 99 City NOP 1W0 7. PROPOSED CASING AND CEMENTING PROGRAM CASING SETTING INFORMATION How Cement Cement Top Setting Formation Weight Setting Hole Size Casing O.D. Grade New Used Set Туре KB/RF Depth TVD (mm) (kg/m) or in-hole Kettle Point Driven nil nil 340 340 81.1 LS New 45 Kettle Point Cement G surface 48.06 H40 244 312 Cement G surface 402 F-Shale 29 76 New 222 178 J55 G 699 A-2 Anhydrite Cement surface 15.62 New 8. BLOW-OUT PREVENTION EQUIPMENT 9" 2M Annular Preventor 7 - 1/16" 3M Annular Preventor and Double Gate Current Balance Total # Unplugged Wells 162 \$70,000 9. WELL SECURITY Name of Trustee Harrison Pensa LLP 10. REMARKS Location Plan X (Land wells only) Drilling Program 11. ENCLOSURES Fee X 12. NOTICE OF COLLECTION The Ministry of Natural Resources is collecting your personal information under the authority of the Oil, Gas and Salt Resources Act. Any personal information provided on If you have questions about use of your personal information, please contact the Policy and Program Officer, Petroleum Resources Centre, Ministry of Natural Resources, 659 lineter Road, London N6E1L3, 519-873-4638.


this application will be used for licensing and law enforcement purposes only and will be protected in accordance with the Freedom of Information and Protection of Privacy Act.

13. AUTHORITY

The undersigned certifies that the information provided herein is complete and accurate, the operator has the right to drill or operate a well in the above

Date (d/m/y) 08.Feb.12 Name		J.E. Sanders	J.E. Sanders Signature		_	
Date of Birth	04,Apr.62	Company	Enbridge Gas Distribution Inc.	Title	Director, Storage Operations	

Filed: 2012-02-15 EB-2012-0060 Attachment 1 Page 2 of 25



Filed: 2012-02-15 EB-2012-0060 Attachment 1 Page 3 of 25

TKC # 63, Moore 6-18-VIII

DRILLING PROGRAM

Filed: 2012-02-15 EB-2012-0060 Attachment 1 Page 4 of 25

TABLE OF CONTENTS

SECTION 1.0 GENERAL DATA

Section 1.1 Well Summary
Section 1.2 Special Notes
Section 1.3 Contact Numbers

SECTION 2.0 GEOLOGICAL PROGNOSIS

SECTION 3.0 CASING AND CEMENTING SUMMARY

Section 3.1 Summary
Section 3.2 Wellbore Diagram
Section 3.3 Wellhead Information

SECTION 4.0 DRILLING PROCEDURES

Section 4.1 Pre-Spud
Section 4.2 Conductor Casing
Section 4.3 Surface Hole and Surface Casing
Section 4.4 Intermediate Hole and Intermediate Casing
Section 4.5 Production Hole and Production Casing
Section 4.6 Main Hole
Section 4.7 Loss Circulation Procedure

SECTION 5.0 REPORTING PROCEDURES

Section 5.1 Tower Sheets Section 5.2 Worker Injury

SECTION 6.0 SAFETY AND PROCEDURES

Section 6.1 General Safety Section 6.2 Well Control

Filed: 2012-02-15 EB-2012-0060 Attachment 1 Page 5 of 25

SECTION 1.0 - GENERAL DATA

Section 1.1 - Well Summary

Well Name: TKC # 63 Moore 6-18-VIII

Operator: Enbridge Gas Distribution Inc.

Surface Location: Tract 6, Lot 18, Con. 8, Moore Twp, Lambton County

Surface Coordinates: 495.0m North; 110.10m East

Ground Elevation: 194.5m

KB Elevation: 195.8m

Total Depth: 740m

Target Formation: A-1 Carbonate

Logging Program: Gamma Ray / Neutron from TD to base of Surface Casing

Porosity / Density Log A-2 Anhydrite to TD

CBL-GR – 114mm casing Vertilog – 114mm casing

Spud Date: March 15th, 2012

Duration: 45 days

Section 1.2 - Special Notes

- 1. Safety of personnel and environment is our primary concern. Section 6.1 of this program, outlines Enbridge's general safety requirements which obliges all personnel on the wellsite to follow the Occupational Health and Safety Act and Regulations (Ministry of Labour) and the Oil, Gas & Salt Resources Act and Regulations (Ministry of Natural Resources). Safety and/or environmental ("tailgate") meetings shall be conducted as per Section 6. Wellsite Supervisor shall conduct daily 'walk around' inspections of the equipment on site and record the results on the daily reports. Please refer to Section 5.2 for the procedure to be followed if a worker injury occurs.
- The Wellsite Supervisor has authority over all activities conducted on the drilling location. The Wellsite Supervisor shall ensure that all applicable regulations and policies (MNR, MOL, MOEE, and Enbridge) are followed and that all permits are kept on site and/or signed off as required.

Filed: 2012-02-15 EB-2012-0060 Attachment 1 Page 6 of 25

- 3. All operations are to be to MNR standards.
- 4. BOPs are to be installed, maintained and used as per MNR requirements. Testing of the BOPs must be in accordance with Section 6.2 of this program.
- 5. Tower sheets must be completed daily and will include the information listed in Section 5.1 of this program. The Wellsite Supervisor will complete daily reports and forward the reports to Enbridge's office by 10am the following day.
- 6. The production casing will be set in the A-2 Anhydrite to allow for an effective cement job and successful pressure testing, prior to penetrating the A-1 Carbonate formation.

Section 1.3 - Contact Numbers

Enbridge Gas Distribution Inc.

Senior Project Geologist Office: 519-862-6032 Kathy McConnell

> 519-862-1168 Fax: Cell: 519-312-2168

kathy.mcconnell@enbridge.com

Office: 519-862-6016 Paul Druet Manager, Reservoir

Development Fax: 519-862-1168 Cell:

519-383-4012 paul.druet@enbridge.com

Office: 519-862-6008 Terry Chupa Land Administrator

Fax: 519-862-1168 519-384-0215 Cell: terry.chupa@enbridge.com

Office: 519-862-6012 Control Room

Drilling Supervisor:

Cell: 519-383-5404 Steve Thompson

omniconsulting@rogers.com

Cell: 519-312-8437 Wayne Bolton kegconsulting@aim.com

Filed: 2012-02-15 EB-2012-0060 Attachment 1 Page 7 of 25

Geologist:

Neil Hoey

Office: 519-472-4776

Fax: 519-472-4776

Cell: 519-649-6918 neil hoey@hotmail.com

Cable Tool Rig - Terry Marsh Well Drilling & Servicing

Terry Marsh

Owner / Operator

Office: 519-695-6060

Fax: 519-695-6464

Cell: 519-359-9804

twmarshca@yahoo.com

Rotary Rig - Bradco Drilling Inc.

Brad Stevenson

Owner / Operator

Office: 519-689-4692

519-689-7516 Fax:

Cell: 519-358-3742

bradco@ciaccess.com

Cementing

Ian Veen

Black Creek Well Service

President

Office: 519-882-4732

519-834-2941

Fax: 519-834-2466

Cell: 519-686-4645

Jay Rookes

Schlumberger Canada

Office: 519-652-5053

Engineer-In-Charge

Fax: 519-652-6002

rookes1@slb.com

Casing & Wellheads - Wellmaster Pipe & Supply Inc.

Andy Arnoczki

Sales Representative

Office: 519-688-0500

Fax:

519-688-0563

Cell:

519-537-0559

aarnoczki@wellmaster.ca

Bill Hedges

Inside Sales

Office: 519-688-0500

Fax:

519-688-0563

bhedges@wellmaster.ca

Graham Shone

Operations Manager

Office: 519-336-9797

519-336-9733

Fax: Cell:

519-331-2534

gshone@cefranklin.com

Filed: 2012-02-15 EB-2012-0060 Attachment 1 Page 8 of 25

Larry Rushton

Owner

Office: 519-326-8884

519-326-8882 Fax:

rushtonsupply@sympatico.ca

Wireline Services

Gord MacKenzie

Baker Atlas Base Manager

Office: 519-332-8030

519-332-4714 Fax:

Cell:

519-339-6783

gord.mackenzie@bakerhughes.com

Dave Tipping

Weatherford Canada -Wireline & Logging

Office: 519-683-2010

Fax:

519-683-2577

Services

Cell:

519-436-3541

Station Manager

dave.tipping@canada.weatherford.com

Snubbing Services

Derrick Jacobson

President

Office: 877-829-7242

Quattro Energy Services Inc.

Fax: Cell:

403-720-6319 403-828-7242

derrick@quattroenergy.ca

Jeff Redmond

Team Snubbing Services

Office: 403-314-4220

Fax:

403-844-2148

Cell:

403-896-8363

jredmond@teamsnubbing.com

Water Hauling

Melvin McKeegan

President

Office: 519-864-1037

McKeegan Trucking Limited

Fax: Cell:

519-864-1036 519-490-4028

Denis Marcus

President

Office: 519-695-3735

Harold Marcus Limited Fax: 519-695-2249

Cell:

519-380-5238

dmarcus@haroldmarcus.com

Aaron Verstraete

President

Office: 519-676-6747

Oil Patch Services

Fax:

519-676-7932

519-380-5473 Cell: ops.aaron@bellnet.ca

Rental Equipment

Derrick Holland

Wheatley Wireline Services

Ltd.

Office: 519-825-3680

Fax:

519-825-9348

Cell:

519-322-8439

dholland891@hotmail.com

Filed: 2012-02-15 EB-2012-0060 Attachment 1 Page 9 of 25

Wade Glass Wheatley Wireline Services Office: 519-825-3680 Ltd. Fax: 519-825-9348 Cell: 519-322-9275 Orval L. Beam Limited Orval Beam Office: 519-436-0164 Operations Manager Fax: 519-436-0164 Tank Rentals Cell: 519-436-4801 Jim Seward JW Seward Enterprises Ltd Office: 519-867-5526 Crane Trucks, Steel Plates Fax: 519-867-5312 Cell: 519-332-7689

Welders - St. Clair Mechanical

John Dawson President Office: 519-864-0927 Fax: 519-864-0801

Cell: 519-330-9672

Government & Other Agencies

MNR Petroleum Resources Centre Office: 519-873-4634

Fax: 519-873-4645 ogsr.mnr.gov.on.ca

MOEE Spill Reporting 1-800-268-6060

MOL Health & Safety 1-800-265-1676

Health & Safety Inspector Office: 519-646-3238

Fax: 519-672-0268

Fax: 519-6/2-0268

Richard Ostrowski Oil, Gas & Salt Resources Office: 519-686-2772 Library Fax: 519-686-7225

richard@ogsrlibrary.com

Police, Fire & 911 Ambulance

Filed: 2012-02-15 EB-2012-0060 Attachment 1 Page 10 of 25

SECTION 2.0

GEOLOGICAL PROGNOSIS

County: Lambton Concession: VIII

Township: Moore

Lot: 18

Tract: 6

Elevation: 196.0m Estimated

Formation	Тор	Elevation	Thickness	Gas	Oil	Water
K.B.	0.0	197.5	1.5			
Drift	1.5	196.0	43.0			Fresh@42.7m
Kettle Point	44.5	153.0	35.6			
Hamilton	80.1	117.4	78.4			
Dundee	158.5	39.0	31.7			
Lucas	190.2	7.3	104.8			Sulphur@196.3m
Amherstburg	0.0	0.0	0.0			
Bois Blanc	294.1	-97.5	49.1			
Bass Islands	343.2	-146.6	48.5			
G-Shale	391.7	-195.1	5.8			
F-Shale	397.5	-200.9	32.3			
F-Salt	429.2	-232.6	45.1			
E-Carbonate	474.3	-277.7	28.3			
D-Salt	502.6	-306.0	7.0			
C-Shale	509.6	-313.0	25.0			
B-Salt	534.6	-338.0	88.1			
A-2 Carbonate	622.7	-426.1	47.9			
A-2 Salt	670.6	-474.0	28.0			
A-2 Anhydrite	698.6	-502.0	1.5			
A-1 Carbonate	700.1	503.5	38.4		700-703	
A-1 Evaporite	738.5	-541.9	4.3			
TD	739.5	-542.9	0.0			

^{***}Note: Prognosis with TVD tops.
***Note: used Imperial No. 603 to build prog


SECTION 3.0 - CASING AND CEMENTING SUMMARY

Section 3.1 - Summary

Hole Size (mm)	Casing Size (mm)	Casing Grade	Casing Weight (kg/m)	Setting Depth (mKB)	How Set
340	340	LS	81.10	45	Driven – cement squeeze if necessary
312	244	H40	48.06	60	Cemented to surface with 100% excess Class G 0-1-0 cement + 2 – 3% CaCl ₂
222	178	J55	29.76	402	Cemented to surface with Class 'G' 0-1-8% plus 1 to 3% CaCl ₂ , followed by Class 'G' neat cement plus 1 to 3% CaCl ₂ . Cement volumes will be calculated with a 50% excess- gel cement and 30% excess – neat cement. Depending upon hole conditions, consideration may be given to running thixotropic cement plus additional loss circulation materials, across porous zone(s).
159	114	J55	15.62	699	Cemented to surface with Class 'G' 0-1-0% plus 1 to 2% CaCl ₂ plus 10% NaCl. Cement volumes will be calculated with a 50% excess on the open hole section and 30% excess on the cased hole section.

Main Hole: 98mm open hole will be drilled from 699m to 740m

Section 3.2 - Wellbore Diagram




Filed: 2012-02-15 EB-2012-0060 Attachment 1 Page 13 of 25

Section 3.3 - Wellhead Summary

Weatherford 13.8 MPa Wellhead:

244mm x 279mm slip on weld on casing bowl for BOP installation 178mm x 229mm slip on weld on casing bowl 229mm x 179mm spool c/w 2 gate valves on side outlets 179mm 13.MPa x 179mm x 20.7 MPa double studded adapter 152mm ANSI 900 Cameron Grove full port ball valve



Filed: 2012-02-15 EB-2012-0060 Attachment 1 Page 14 of 25

SECTION 4.0 - DRILLING PROCEDURES

Section 4.1 - Pre Spud

1. Fresh Water Well Samples

Obtain samples from all fresh water wells located within a 750 metre radius of the proposed well. Have routine water analysis done on all water samples by an independent laboratory in Sarnia. Ensure that copies of these reports are placed in the well files in Enbridge's office

2. Site Preparation

Prepare drilling location as follows:

- a. Locate all drainage tiles crossing lease area
- b. Strip and properly stock pile all soil from the lease
- c. Cut, block and divert drainage tiles as required
- d. Construct adequate berms around lease and access road as required

3. Government Notification of Spud

48 hours prior to spud, notify the Ministry of Natural Resources – Petroleum Resources Section by fax @ (519) 873 – 4645 of the date of commencement of drilling operations

4. Signs

Install rig signs on access road to lease.

5. Safety Meeting

Conduct a pre-spud safety meeting for Rig crews. Tool push and all crewmembers must be present. A similar meeting shall be conducted with the remaining crew(s) as they come on duty. Additional safety meetings shall be conducted as per Section 6.1 of this program.

Section 4.2 - Conductor Casing

1. Drilling Method

Move in and rig up Cable Tool Rig. Measure and record the distance from RF to ground and the RF elevation – include these measurements on the tower sheets and the daily report. Drill and drive 340mm casing to bedrock, to an approximate depth of 45m. Note any occurrence of water and record type of water, depth encountered, and static level of water and/or flow rate. If fresh water is encountered during

Filed: 2012-02-15 EB-2012-0060 Attachment 1 Page 15 of 25

drilling, the well must be bail tested for at least 15 minutes, after the casing is landed, to ensure that the fresh water has been shut-off. If the fresh water has not been shut-off, contact Enbridge's office and be prepared to perform a cement squeeze as per Enbridge's requirements.

2. Cement Squeeze (if necessary)

If fresh water is found in the drift and is not shut-off by the conductor casing, a flow rate will be established and a cement squeeze will be performed, using the cement volumes determined by Enbridge. Wait on cement 12 hours and bail the hole dry and monitor the well for at least 15 minutes to determine if the water has been shut-off. If necessary, the process will be repeated until the water is shut-off.

Section 4.3 - Surface Hole & Surface Casing

1. Drilling Method

Drill a 312mm hole 15 metres \pm into the Kettle Point formation, to an approximate depth of 60m. Ensure that drill cutting samples are taken every 3 metres and placed in the sample bags provided by the Ministry of Natural Resources. The sample bags must be labeled with the well name, Township, Lot, Concession and Enbridge's name. Record on daily drilling reports any influx of fluids and/or hydrocarbons, static levels, pressures and any unusual hole conditions.

2. Casing Installation

Depending upon hole conditions encountered, the 244mm casing will be run in the following manner:

- Texas Shoe on bottom of first joint
- Centralizers on the top and bottom of the first joint and coincident with the shoe of the conductor casing
- 244mm casing to surface

3. Cementing Procedures

Move in and rig up Cementers. Ensure pressure recorder is rigged in and serviceable. Pressure charts will be attached to the job ticket. Conduct a pre-job safety meeting to confirm volumes and procedures. Establish circulation using pump truck. The casing and the hole will be circulated with fresh water for 15 minutes to clean the borehole and to fill the casing and hole prior to cementing. Pressure test surface equipment to 14 MPa. Ensure that preflush and mix water are from a clean source and that the water trucks are uncontaminated. Pump preflush of 2.0m³ of fresh water, with the addition of loss circulation material if necessary. Ensure that a minimum of 4 cement samples are taken and represent the cement at the beginning, middle and end of the cement job. Mix and pump sufficient Class 'G' 0-1-0% cement plus 2 to 3% CaCl₂

Filed: 2012-02-15 EB-2012-0060 Attachment 1 Page 16 of 25

with a density of 1901 kg/m³ to cement the casing to surface with 100% excess. Displace cement with fresh water – ensure that cement is under displaced and that the bottom joint of casing is full of cement. Shut-in cementing valve at surface and wait on cement at least 12 hours before slacking off casing.

- 4. Install 244mm x 279mm slip on weld on casing bowl for BOP installation. Arrange to have surface hole cuttings solidified and then disposed in an approved manner.
- 5. Release the Cable Tool Rig.

Section 4.4 - Intermediate Hole & Intermediate Casing

1. BOP Installation and Pressure Testing

Move in and rig up Rotary Rig. Measure and record the distance from KB to ground and the KB elevation – include these measurements on the tower sheets and the daily report.

Install Class A (Rotary) BOPs as per MNR requirements. After BOPs are installed and the cement samples indicate that the cement is competent, the rig will proceed to pressure test the BOPs, casing and shoe. Pressure test casing and each component of the BOPs as per Section 6.2. After successfully pressure testing the BOPs and casing, drill out cement and 0.5m of new formation and conduct a PIT, with the hole full of fresh water, using a bottom hole pressure equivalent to 18 kPa/m.

2. Drilling Method

Drill a 222mm hole with fresh water to 5m ± into the F Shale formation, to an approximate depth of 402m. Notify Geologist 12 hours in advance of reaching intermediate casing point, so that they can be on site to determine the proper casing setting depth. When casing setting depth has been determined, circulated the hole clean. Perform a flow check prior to tripping and strap out of the hole. Fast tripping of the drill string is to be avoided in order to eliminate high annular velocities, pressure surges and swabbing (maximum rate of 27 metres per minute). Keeping the hole full of fluid, trip out of the hole and laydown bottom hole assembly and depending upon rotary rig type, standback or laydown drill collars and drill pipe.

The potential for loss circulation exists while drilling through the Detroit River formations (Lucas and Amherstburg formations). If loss circulation is encountered use the loss circulation contingency program located in Section 4.7. Note all lost circulation intervals and monitor and record fluid loss volumes. If pit fluid must be hauled to disposal, keep solid content to a minimum to reduce costs.

Ensure that drill cutting samples are taken every 3 metres and placed in the sample bags provided by the Ministry of Natural Resources. Record on daily tower sheets

Filed: 2012-02-15 EB-2012-0060 Attachment 1 Page 17 of 25

any influx of fluids and static levels (water and/or hydrocarbons), gas and/or any unusual hole conditions.

3. Casing Installation

Ensure that the threads are protected while hoisting casing to the floor. Drift all casing prior to running the casing in the well and apply proper API make-up torque to each connection.

Depending upon hole conditions encountered, the 178mm casing will be run in the following manner:

- Guide shoe
- 178mm joint of casing
- 178mm Float Insert or Float Collar
- Tack weld guide shoe, float collar and bottom 2 joints and use API modified pipe dope on all connections
- Centralizers will be installed one metre above the guide shoe, over the bottom of the first 2 collars and every 5 joints to surface
- 178mm casing to surface

4. Cementing Procedures

Move in and rig up Cementers. Ensure pressure recorder is rigged in and serviceable. Pressure charts will be attached to the job ticket. Conduct a pre-job safety meeting to confirm volumes and procedures. Fill hole and establish circulation using pump truck. The casing and the hole will be circulated with fresh water for 15 minutes to clean the borehole and to fill the casing and hole prior to cementing. Pressure test surface equipment to 14MPa for 10 minutes. Preflush and mix water must be obtained from a clean source and the water trucks must be uncontaminated. Pump preflush of 3.0m³ of fresh water, with the addition of loss circulation material if necessary. Ensure that a minimum of 4 cement samples are taken and represent the cement at the beginning, middle and end of the cement job. Mix and pump sufficient 0-1-8 Class 'G' cement plus 1 to 3% CaCl2 (50% excess) followed by 0-1-0 Class 'G' cement plus 1 to 3% CaCl₂ (30% excess) to cement casing to surface. Depending upon the severity of the loss circulation zones, thixotropic cement with additional loss circulation materials may be used to cover the loss zone. If there are no cement returns to surface, a feed rate will be established and the annulus will be grouted to surface. Drop wiper plug and displace cement and bump plug to 3.5 Mpa over final pumping pressure - do not exceed 60% of internal yield pressure of casing. Once plug is bumped and it is determined that the float is holding, bleed casing pressure back to final pumping pressure, close casing valves and bleed off surface line pressure and wash out BOPs. Wait on cement 24 hours before slacking off casing. Remove 244mm x 279mm casing bowl and install 178mm x 229mm casing bowl on the 178mm casing.

Filed: 2012-02-15 EB-2012-0060 Attachment 1 Page 18 of 25

Section 4.5 - Production Hole & Production Casing

1. Pressure Testing

Check cement samples for hardness – if cement samples are set to the satisfaction of the Wellsite Supervisor, proceed with installation of the BOPS. Install Class B (Rotary) BOPs as per MNR requirements on 178mm casing bowl. After BOPs are installed and the cement samples indicate that the cement is competent, the rig will proceed to pressure test the BOPs, casing and shoe. Pressure test casing and each component of the BOPs as per Section 6.2. After successfully pressure testing the BOPs and casing, drill out cement and 0.5m of new formation and conduct a PIT, with the hole full of fresh water, using a bottom hole pressure equivalent to 18 kPa/m.

2. Drilling Method

Drill a 159mm hole using brine to prevent the dissolution of the salt layers. Ensure that drill cutting samples are taken every 3 metres and placed in the sample bags provided by the Ministry of Natural Resources. Record on daily tower sheets any influx of fluids and static levels (water and/or hydrocarbons), gas and any unusual hole conditions.

Prior to penetrating the A-2 Carbonate, the Wellsite Geologist and Wellsite Supervisor must be on-site and a BOP drill shall be completed to familiarize all on-site personnel with the proper procedures.

Drill a 159mm hole $1 \pm$ metres into the A-2 Anhydrite formation, to an approximate depth of 699m. The final casing point will be determined by the Wellsite Geologist.

If the reef pressure is above 7000kPa, drilling will be suspended and the rig will be moved off location after the 114mm casing is installed and cemented. The rig will be brought back onto location to complete the drilling of the well when the reef pressure is below 7000kPa.

3. Casing Installation

Ensure that the threads are protected while hoisting casing to the floor. Drift all casing prior to running the casing in the well and apply proper API make-up torque to each connection.

Depending upon hole conditions encountered, the 114mm casing will be run in the following manner:

- Guide shoe
- 114mm joint of casing
- Float Insert or Float Collar
- Tack weld guide shoe, float collar and bottom 4 joints and use API modified pipe dope on all connections

Filed: 2012-02-15 EB-2012-0060 Attachment 1 Page 19 of 25

- Centralizers will be installed on bottom 5 joints of casing on every 5th joint to surface
- 114mm casing to surface

4. Cementing Procedures

Move in and rig up Cementers. Ensure pressure recorder is rigged in and serviceable. Pressure charts will be attached to the job ticket. Conduct a pre-job safety meeting to confirm volumes and procedures.

Establish circulation using pump truck. The casing and the hole will be filled with brine and circulated for 15 minutes to clean the borehole and to fill the casing and hole prior to cementing. Pressure test surface equipment to 14 MPa for 10 minutes. Preflush and mix water must be obtained from a clean source and the water trucks must be uncontaminated. Pump preflush of 3.0m3 of clean brine, with the addition of loss circulation material if necessary. Ensure that a minimum of 4 cement samples are taken and represent the cement at the beginning, middle and end of the cement job. Mix and pump sufficient Class 'G' 0-1-0 cement plus 10% NaCl, to cement the 114mm casing to surface plus 50% excess over open hole and 30% excess in cased hole. Drop wiper plug and displace cement with fresh water and bump plug to 3500 kPa over final pumping pressure - do not exceed 60% of internal yield pressure of casing. Once plug is bumped and it is determined that the float is holding, bleed casing pressure back to final pumping pressure, close casing valves and bleed off surface line pressure. Wash out BOPs and split BOP stack at 229mm flange, install 114mm slips and set slips in casing bowl. Wait on cement 24 hours and cut casing and remove BOPs. Cut and bevel 114mm casing and install primary and secondary seals. Install 229mm x 179mm spool piece and and test wellhead seals to 14 Mpa for 10 minutes. Install 179mm 14MPa x 21MPa double studded adapter and ANSI 900 Master Valve and shut-in well. 48 hours after cementing operations have been completed - pressure test casing, wellhead and master valve to 12,410kPa for a minimum of 4 hours - ensure that a digital pressure gauge is installed. Report results to the Enbridge Office - do not proceed with BOP installation until the pressure test has been successfully completed.

If the Master Valve is too high above the drill floor, the BOPs will be installed on the top of the spool piece and when the well is completed, a WR-1 plug will be set in the base of the casing and successfully pressure tested to 8300 kPa. The BOPs will then be removed and the Master Valve installed. Once the Master Valve has been installed and successfully pressure tested, the plug will be retrieved with a Wireline Service company.

Section 4.6 - Main Hole

1. Installation of the BOPs

Check cement samples for hardness – if cement samples are set to the satisfaction of the Wellsite Supervisor, proceed with installation of the BOPS. Install Class B

Filed: 2012-02-15 EB-2012-0060 Attachment 1 Page 20 of 25

(Rotary) BOPs as per MNR requirements. After BOPs and lubricator are installed and a minimum of 48 hours 'wait-on-cement-time' has passed and the cement samples indicate that the cement is competent, a cement bond log will be run on the 114mm casing. Consideration may be given to moving out the Rotary Rig and moving in a Cable Tool Rig. The Cable Tool Rig will install Class B (Cable Tool) BOPs.

2. Logging

Move in and rig up Wireline Company. With hole full of fresh water, run a Cement Bond Log, both a non-pressure and pressure pass. Run a Gamma-Ray / Neutron Log from TD to the base of the surface casing. Rig out Wireline Company and release.

3. Drilling Method

Each component of the BOPs and the casing will be pressure tested as per Section 6.2. Upon successful completion of the pressure testing of the BOPs, the cement, shoe and 0.5m of new formation will be drilled out and a PIT will be conducted, with the hole full of fresh water, using a bottom hole pressure equivalent to 18 kPa/m.

Drill a 98mm hole through the A-1 Carbonate and 1 metre into the A-1 Evaporite Formation – final TD will be determined by the Wellsite Geologist. While drilling the main hole ensure that drill cutting samples are taken every 3 metres and placed in the sample bags provided by the Ministry of Natural Resources. Record on daily tower sheets any influx of fluids and static levels (water and/or hydrocarbons), gas and any unusual hole conditions.

Drilling of the well may be suspended if sufficient permeability and porosity are encountered prior to reaching the proposed TD. If drilling is suspended, the rig will be moved off location and a variety of pressure tests will be performed on the well during withdrawal / injection operations. If the testing of the well shows that the porosity and permeability of the well are not suitable, a rig will be moved back onto location and the well will be drilled to the original TD-1 metre into the A-1 Evaporite.

4. Logging

Move in and rig up Wireline Company to run a Gamma-Ray/Neutron/Density Log over the open hole section of the well and run a Casing Inspection Log over the 114mm casing.

5. BOP Removal

Close master valve and nipple down BOPs and install 152mm (6") blind flange. If the master valve was not used for the drilling of the well — move in and rig up Wireline and Tool Companies and install a WR-1 plug in the base of the 114mm casing. Bleed down and fill the well with fresh water and pressure test the plug to

Filed: 2012-02-15 EB-2012-0060 Attachment 1 Page 21 of 25

8300 kPa. Upon successful completion of the pressure test, remove BOPs and install master valve. Install a digital pressure recorder and pressure test casing, wellhead and master valve, with the hole full of fresh water to a surface pressure of 12,410kPa for a minimum of 4 hours. Report results to Enbridge Office. Do not rig down until well passes the pressure test. Move in Wireline Company to retrieve WR-1 plug.

- 6. Rig down rotary rig and move off of location.
- 7. Restore wellsite to Enbridge's specifications.

Section 4.7 - Loss Circulation Procedure

- 1. Before drilling out the casing shoe:
 - a. Identify sources and location of fresh water and/or brine, loss circulation materials and weight materials
 - b. Ensure BOPs and manifold are properly installed
 - c. Ensure auxiliary tanks are connected to the pumping system and a standby mud pump is hooked up for annular injection in case of severe loss circulation (so that fluid can be pumped down both the drill pipe and annulus simultaneously)
 - d. Pressure test BOPs prior to drill out

2. After drilling out shoe:

- a. Alert water suppliers and haulers
- b. Ensure adequate amounts of fresh water and/or brine are readily available prior to penetrating the Detroit River formation.
- c. Mechanically test BOPs and perform BOP drill prior to penetrating the Detroit River formation.
- 3. Drilling Blind Detroit River formations:
 - a. In an attempt to maintain or re-establish circulation, pump fluid down both the annulus and the drill pipe simultaneously
 - b. Should severe loss circulation occur while drilling, the thief zone may be plugged with cement and/or loss circulation material at Enbridge's discretion.

Filed: 2012-02-15 EB-2012-0060 Attachment 1 Page 22 of 25

SECTION 5.0 - REPORTING PROCEDURES

Section 5.1 - Tower Sheets

Shall be completed daily and shall include:

- 1. Bit size, jars, depth at the beginning of the shift and end of each shift.
- 2. Casing size, grade, weight, and number of joints, centralizers, cement baskets, total length and setting depth.
- 3. Cementing information Service Company, cement type, amount, slurry density, additives, annular fluid returns, volume of displacement fluid and plug down time.
- 4. Water, gas or oil type, depth encountered depth of sample collected and the static level and/or rate of flow.
- 5. Pressure tests individually, surface pressures, fluid density used in the tests, bleed-off rate and duration of test.
- 6. Logging Details type and interval.
- 7. Abandonment details intervals, amount and type of cement, top of plug and time felt.
- 8. Rig release date and time.

Section 5.2 - Worker Injury

Every work related accident or injury shall be reported immediately to the Wellsite Supervisor. The Supervisor shall immediately contact the Ministry of Labour @ 1-800-265-5140 and the Ministry of Natural Resources @ 519-873-4634. The verbal report shall be followed with a written report as per the Occupational Health and Safety Act and the Oil, Gas & Salt Resources Act and Section 13 of the Operational Standards. The Supervisor will also be responsible for notifying the Operator (Enbridge Gas Distribution Inc.) and shall be responsible for the completion of Enbridge's Accident Report Form.

Filed: 2012-02-15 EB-2012-0060 Attachment 1 Page 23 of 25

SECTION 6.0 - SAFETY AND PROCEDURES

Section 6.1 - General Safety

- 1. All works at the wellsite shall be in compliance with the Occupational Health and Safety Act and the Oil, Gas & Salt Resources Act and all associated legislation. In addition, all work at the wellsite shall be done in compliance with good oil field practices. All verbal notifications given to and approvals received from government agencies shall be recorded on the tower sheets.
- 2. The Enbridge 'Job Safety Analysis Form' (JSA) shall be thoroughly reviewed by the Wellsite Supervisor with all onsite personnel through the daily safety meetings and any changes to the JSA will be noted on the Enbridge Safety Meeting / Tool Box Form.
- 3. Daily safety ('tailgate') meetings are to be conducted with each shift and recorded on the Enbridge Safety Meeting / Tool Box Form. Additional safety meetings are to be held with each crew, at the start of the well and safety meetings shall also be held prior to cementing and upon arrival of the logging company and prior to penetrating the Detroit River formations and the A-2 Carbonate formation.
- 4. The Wellsite Supervisor shall ensure that the operations are in compliance with all applicable government regulations and shall complete daily walk around rig inspections and record the results on their daily reports.

Section 6.2 - Well Control

All blowout prevention systems are to be in strict compliance with MNR regulations. The function and pressure testing guidelines required by the regulatory bodies (such as daily function testing of the pipe rams) will be strictly adhered to.

- 1. All pressure tests of blowout prevention equipment will be conducted with fresh water and will be conducted in 2 stages low and high pressure. It is essential that the low pressure test be done first, to prevent the high pressure test from healing leaks that would have been noted at low pressures.
- 2. The following pressure tests will be conducted with fresh water prior to drilling out each casing string and the results recorded on the tower sheets and daily reports:

Rotary:

- a. The blind rams, kill lines and choke manifold and casing will be tested individually for 10 minutes each to:
 - i. Intermediate casing 2000 kPa low & 9000 kPa high
 - ii. Production casing 2000 kPa low and 10000 kPa high

Filed: 2012-02-15 EB-2012-0060 Attachment 1 Page 24 of 25

- b. Run in hole with BHA, drill pipe and drill collars and pressure test the pipe rams, kelly cock, stand pipe, swivel, safety valves, etc. will be tested individually for 10 minutes each to:
 - i. Surface casing 1400 kPa low and 3500 kPa high (using AP)
 - ii. Intermediate casing 2000kPa low & 9000 kPa high
 - iii. Production casing 2000 kPa low and 10000 kPa high
- c. The annular preventer will be tested for 10 minutes to
 - i. Surface casing 1400 kPa low and 3500 kPa high
 - ii. Intermediate casing 2000 kPa low & 9000 kPa high
 - iii. Production casing 2000 kPa low and 10000 kPa high

Cable Tool:

- a. The blind rams, kill lines and casing will be tested individually for 10 minutes each to:
 - i. Intermediate casing 2000 kPa low & 8000 kPa high
 - ii. Production casing 2000 kPa low and 10000 kPa high
- b. Function test the pipe rams / shear rams, safety valves, etc. individually for 10 minutes each to:
 - i. Intermediate casing 2000kPa low & 8000 kPa high
 - ii. Production casing 2000 kPa low and 10000 kPa high
- c. The annular preventer will be tested for 10 minutes to
 - i. Surface casing 1400 kPa low and 3500 kPa high
 - ii. Intermediate casing 2000 kPa low & 8000 kPa high
 - iii. Production casing 2000 kPa low and 10000 kPa high
- d. The lubricator system will be tested for 10 minutes to
 - i. Production casing 2000 kPa low and 8000 kPa high
- e. A full lubricator system will be required when:
 - i. gas is encountered with H2S content greater than 100ppm,
 - ii. when crude oil flows to surface or is capable of unloading during bailing operations, or
 - iii. when flows of natural gas exceed 7.0 10³m³/D (250Mcfd).
- 2. Upon drilling out the casing, drill 0.5m to 1.0m of new hole and test the formation, with the hole full of fresh water, to a minimum bottom hole pressure of 18 kPa per metre.
- 3. After one day of drilling below the casing shoe, check the entire blowout prevention system and tighten all bolts.

Filed: 2012-02-15 EB-2012-0060 Attachment 1 Page 25 of 25

- 4. Crews should be kept alert and familiar with the blowout prevention equipment. At least one member of the crew who has been trained in blowout prevention and well control procedures must be on the floor at all times.
- 5. Conduct blowout prevention drills prior to drilling out casing and once per week thereafter. Ensure that the drills are recorded in the tour book.
- 6. The blowout preventers are to be function tested once per tour. Ensure that the function test is recorded on the tower sheets.



Oll, Gas and Salt Resources Act

Application for a Well Licence

Filed: 2012-02-15 EB-2012-0060 Attachment 4


Form 1

To the Minister of Natural Resources

Page 1 of 25 v.2010-07-01 The undersigned operator applies for a well licence under the Oil, Gas and Salt Resources Act and the Regulations thereunder and submits

the following	information, to	ogether with	the applic	ation fee of \$1	100 + 13% HST	Γ.				
1. WELL N	1. WELL NAME TKC # 66 Moore 1-16-VIII					Target Formation A-1			onate	
Purpose of Proposed Well (Well Type) Observation Well										
2. OPERAT	OR		Enbrid	ge Gas Distril	bution Inc.		Tel# 519-86	32-1473	Fax #5	19-862-1168
Street Addre	ess		3595 Te	cumseh Road	<u> </u>	044	Mooretown	Prov. ON	N Postei Code	NON 1M0
Mailing Addr	ess		3595 Te	cumseh Road	1	City	Mooretown	Prev Of	N Pastar Core	NON 1M0
Contact Name Kathy McConnell Contact Tel # 519-862-6032										
3. LOCATION County Lambton Township Moore										
Tract 1	Lot	16	Conces	ssion	VIII	Lake Erl	e: <u>8000</u> k Y	eoi Lis	seculueuna tia	
Surface loca	tion,	<u>117</u> m	North _] South X	Latitude	42 ⁰ 51'39.0)12" Bott	om-hole Lat.	42 ⁰ 51	39.012"
metres from Lot Boundari	ies <u>1</u>	19.5 m	East	WestX	Longitud	e 82 ⁰ 20'59	.680" Bott	om-hole Long.	82 ⁰ 2	0'59.680"
Within 1.6 km of Designated Storage Area? Yes X No Off-target? Yes No X										
4. WELL PA	ARTICULARS		Vertical X] Horiz	zontal 🗌	Directional	Deepening	Re-en	try La	teral
Rig Type:	RotaryX	Cable	X	Well to be co	ored? Yes[No X	Formation at Ti	D	A-1 Evapor	ite
Ground Elev	ation 19	5.5 Pr	oposed De	epth 727	.0 Propo	sed Depth TVD	727.00 P	roposed Start	Date	15.Mar.12
5. LANDOW	NER							Tel #		
Street Addre	ss				13	Cdy		Frov.	Postvi Coc	÷
The landowner herby provides consent for the collection of their personal information, via the operator, as per Section 12 of this form. Landowner Signature:										
Pooling of the Spacing Unit or unitization of the Unit Area shown on the attached well location plan has been completed (see Ont. Reg. 245/97 definitions for "pooled spacing unit" and "unitize") 6. DRILLING CONTRACTOR T.W. Marsh Well Drilling and Servicing / Bradco Drilling Inc. Tel # 519-695-6060 / 519-689-4692										
Address		Box 5	53 / 14 Hat	tie St., Box 99		Gly I	Bothwell / Merlin	sercia. C	N Poster Cor	NOP 2C0 /
7. PROPOS	ED CASING	AND CEME	NTING PI	ROGRAM				CASING	SETTING INF	ORMATION
Hole Size	Casing O.D.	Weight (kg/m)	Grade	New, Used	Setting Depth TVD	Setting Fo	ormation	How Set	Cement Type	Cement Top KB / RF
340	340	81.1	LS	New	42	Kettle	Point	Driven	nll	nil
312	244	48.06	H40	New	57	Kettle		Cement	G	surface surface
222 159	178	29.76 15.62	J55 J55	New New	392 686	F-St A-2 Ani		Cement	G	surface
139		10.02								
8. BLOW-O	UT PREVENT	ION EQUI	PMENT	9" 21	V Annular Prev	entor				
				7 - 1	/16" 3M Annula	r Preventor and Do	ouble Gate			
9. WELL SECURITY Name of Trustee Harrison Pensa LLP Total # Unplugged Wells 162 Current Balance \$70,000										
10. REMARKS										
11. ENCLOSURES Fee X Location Plan X (Land wells only) Drilling Program X										
The Ministry o	n will be used fo	rces Is colle or Ilcensing a	ınd law enfo	rcement purpos	ses only and will	nthority of the OII, Ga be protected in accor Petroleum Resources Centr	rdance with the Free	edom of Informa	tion and Protecti	on of Privacy Act.
13. AUTHOR		hat the info	rmation pro	ovided herein i	s complete and	l accurate, the oper	rator has the right	to drill or opera	ate a well in the	above
	he/she has at							_		\neg
Date (d/mvy)	08.Fel	b.12	Name		J.E. Sand	ers	Signature		(Original Signe	
Date of Birth	04.A	pr.62	Company	En	bridge Gas Dis	tribution Inc.	Title	Director, S	Storage Operat	ions

Filed: 2012-02-15 EB-2012-0060 Attachment 4 Page 2 of 25



TKC # 66, Moore 1-16-VIII

DRILLING PROGRAM

Filed: 2012-02-15 EB-2012-0060 Attachment 4 Page 4 of 25

TABLE OF CONTENTS

SECTION 1.0 GENERAL DATA

Section 1.1 Well Summary
Section 1.2 Special Notes
Section 1.3 Contact Numbers

SECTION 2.0 GEOLOGICAL PROGNOSIS

SECTION 3.0 CASING AND CEMENTING SUMMARY

Section 3.1 Summary
Section 3.2 Wellbore Diagram
Section 3.3 Wellhead Information

SECTION 4.0 DRILLING PROCEDURES

Section 4.1 Pre-Spud
Section 4.2 Conductor Casing
Section 4.3 Surface Hole and Surface Casing
Section 4.4 Intermediate Hole and Intermediate Casing
Section 4.5 Production Hole and Production Casing
Section 4.6 Main Hole
Section 4.7 Loss Circulation Procedure

SECTION 5.0 REPORTING PROCEDURES

Section 5.1 Tower Sheets Section 5.2 Worker Injury

SECTION 6.0 SAFETY AND PROCEDURES

Section 6.1 General Safety Section 6.2 Well Control

Filed: 2012-02-15 EB-2012-0060 Attachment 4 Page 5 of 25

SECTION 1.0 - GENERAL DATA

Section 1.1 - Well Summary

Well Name:

TKC # 66 Moore 1-16-VIII

Operator:

Enbridge Gas Distribution Inc.

Surface Location:

Tract 1, Lot 16, Con. 8, Moore Twp, Lambton County

Surface Coordinates:

117.0m South; 119.5m West

Ground Elevation:

195.50m

KB Elevation:

196.80m

Total Depth:

727m

Target Formation:

A-1 Carbonate

Logging Program:

Gamma Ray / Neutron from TD to base of Surface Casing

Porosity / Density Log A-2 Anhydrite to TD

CBL-GR – 114mm casing Vertilog – 114mm casing

Spud Date:

March 15th, 2012

Duration:

45 days

Section 1.2 - Special Notes

- 1. Safety of personnel and environment is our primary concern. Section 6.1 of this program, outlines Enbridge's general safety requirements which obliges all personnel on the wellsite to follow the Occupational Health and Safety Act and Regulations (Ministry of Labour) and the Oil, Gas & Salt Resources Act and Regulations (Ministry of Natural Resources). Safety and/or environmental ("tailgate") meetings shall be conducted as per Section 6. Wellsite Supervisor shall conduct daily 'walk around' inspections of the equipment on site and record the results on the daily reports. Please refer to Section 5.2 for the procedure to be followed if a worker injury occurs.
- The Wellsite Supervisor has authority over all activities conducted on the drilling location. The Wellsite Supervisor shall ensure that all applicable regulations and policies (MNR, MOL, MOEE, and Enbridge) are followed and that all permits are kept on site and/or signed off as required.

Filed: 2012-02-15 EB-2012-0060 Attachment 4 Page 6 of 25

- 3. All operations are to be to MNR standards.
- 4. BOPs are to be installed, maintained and used as per MNR requirements. Testing of the BOPs must be in accordance with Section 6.2 of this program.
- 5. Tower sheets must be completed daily and will include the information listed in Section 5.1 of this program. The Wellsite Supervisor will complete daily reports and forward the reports to Enbridge's office by 10am the following day.
- 6. The production casing will be set in the A-2 Anhydrite to allow for an effective cement job and successful pressure testing, prior to penetrating the A-1 Carbonate formation.

Section 1.3 - Contact Numbers

Enbridge Gas Distribution Inc.

Kathy McConnell Senior Project Geologist Office: 519-862-6032 Fax: 519-862-1168 Cell: 519-312-2168

kathy.mcconnell@enbridge.com

Paul Druet Manager, Reservoir Office: 519-862-6016
Development Fax: 519-862-1168

Cell: 519-383-4012 paul.druet@enbridge.com

Terry Chupa Land Administrator Office: 519-862-6008

Fax: 519-862-1168 Cell: 519-384-0215 terry.chupa@enbridge.com

Control Room Office: 519-862-6012

Drilling Supervisor:

Steve Thompson Cell: 519-383-5404

omniconsulting@rogers.com

Wayne Bolton Cell: 519-312-8437

kegconsulting@aim.com

Filed: 2012-02-15 EB-2012-0060 Attachment 4 Page 7 of 25

Geologist:

Neil Hoey Office: 519-472-4776

Fax: 519-472-4776 Cell: 519-649-6918 neil_hoey@hotmail.com

Cable Tool Rig - Terry Marsh Well Drilling & Servicing

Terry Marsh Owner / Operator Office: 519-695-6060

Fax: 519-695-6464 Cell: 519-359-9804 twmarshca@yahoo.com

Rotary Rig - Bradco Drilling Inc.

Brad Stevenson Owner / Operator Office: 519-689-4692

Fax: 519-689-7516 Cell: 519-358-3742 bradco@ciaccess.com

Cementing

Ian Veen Black Creek Well Service Office: 519-882-4732

President 519-834-2941

Fax: 519-834-2466 Cell: 519-686-4645

Jay Rookes Schlumberger Canada Office: 519-652-5053

Engineer-In-Charge Fax: 519-652-6002

rookes1@slb.com

Casing & Wellheads – Wellmaster Pipe & Supply Inc.

Andy Arnoczki Sales Representative Office: 519-688-0500

Fax: 519-688-0563 Cell: 519-537-0559 aarnoczki@wellmaster.ca

Bill Hedges Inside Sales Office: 519-688-0500

Fax: 519-688-0563 bhedges@wellmaster.ca

Graham Shone Operations Manager Office: 519-336-9797

Fax: 519-336-9733 Cell: 519-331-2534 gshone@cefranklin.com Larry Rushton

Owner

Office: 519-326-8884

Fax: 519-326-8882

rushtonsupply@sympatico.ca

Wireline Services

Gord MacKenzie

Baker Atlas

Base Manager

Office: 519-332-8030

Fax: 519-332-4714

Cell: 519-339-6783

gord.mackenzie@bakerhughes.com

Dave Tipping

Weatherford Canada -

Wireline & Logging

Services

Office: 519-683-2010

519-683-2577 Fax:

Cell: 519-436-3541

Station Manager

dave.tipping@canada.weatherford.com

Snubbing Services

Derrick Jacobson

President

Quattro Energy Services

Office: 877-829-7242

Fax: 403-720-6319

Cell: 403-828-7242

derrick@quattroenergy.ca

Jeff Redmond

Team Snubbing Services

Inc.

Office: 403-314-4220

Fax: 403-844-2148

Cell: 403-896-8363 jredmond@teamsnubbing.com

Water Hauling

Melvin McKeegan

President

McKeegan Trucking

Limited

Office: 519-864-1037 519-864-1036

Fax: Cell:

519-490-4028

Denis Marcus

President

Harold Marcus Limited

Office: 519-695-3735

519-695-2249 Fax:

Cell: 519-380-5238

dmarcus@haroldmarcus.com

Aaron Verstraete

President

Oil Patch Services

Office: 519-676-6747

Fax: 519-676-7932

Cell:

519-380-5473

ops.aaron@bellnet.ca

Rental Equipment

Derrick Holland

Wheatley Wireline Services

Ltd.

Office: 519-825-3680

519-825-9348 Fax:

Cell:

519-322-8439

dholland891@hotmail.com

Filed: 2012-02-15 EB-2012-0060 Attachment 4 Page 9 of 25

Wheatley Wireline Services Wade Glass Office: 519-825-3680 Ltd. Fax: 519-825-9348 Cell: 519-322-9275 Orval Beam Orval L. Beam Limited Office: 519-436-0164 Operations Manager 519-436-0164 Fax: Tank Rentals Cell: 519-436-4801 Jim Seward JW Seward Enterprises Ltd Office: 519-867-5526 Crane Trucks, Steel Plates Fax: 519-867-5312 Cell: 519-332-7689 Welders - St. Clair Mechanical Office: 519-864-0927 John Dawson President Fax: 519-864-0801 Cell: 519-330-9672 Government & Other Agencies MNR Petroleum Resources Centre Office: 519-873-4634 Fax: 519-873-4645 ogsr.mnr.gov.on.ca MOEE Spill Reporting 1-800-268-6060 MOL Health & Safety 1-800-265-1676 Health & Safety Inspector Office: 519-646-3238 Fax: 519-672-0268 Richard Ostrowski Office: 519-686-2772 Oil, Gas & Salt Resources Library Fax: 519-686-7225

Police, Fire &

Ambulance

richard@ogsrlibrary.com

911

Filed: 2012-02-15 EB-2012-0060 Attachment 4 Page 10 of 25

SECTION 2.0

GEOLOGICAL PROGNOSIS

County: Lambton

Township: Moore

Concession: VIII

Lot: 16

Tract: 1

Formation	Тор	Elevation	Thickness	Gas	Oil	Water
K.B.	0.0	197.8	1.5			
Drift	1.5	196.3	39.6			Fresh@36.6m
Kettle Point	41.1	156.7	20.9			
Hamilton	62.0	135.8	80.3			
Dundee	142.3	55.5	33.4			Sulphur@150.9m
Detroit River	175.7	22.1	150.7			
Bass Islands	326.4	-128.6	53.1			
G-Shale	379.5	-181.7	7.3			
F-Shale	386.8	-189.0	36.4			
F-Salt	423.2	-225.4	39.0			
E-Carbonate	462.2	-264.4	30.3			
D-Salt	492.5	-294.7	5.9			
C-Shale	498.4	-300.6	27.7			
B-Salt	526.1	-328.3	82.0			
A-2 Carbonate	608.1	-410.3	45.3			
A-2 Salt	653.4	-455.6	31.5			
A-2 Anhydrite	684.9	-487.1	2.4			
A-1 Carbonate	687.3	-489.5	38.7	690m	690m	
A-1 Evaporite	726.0	-528.2	1+			
TD	727.0					

^{***}Note: used Imperial Colinville No. 4 to build prog


SECTION 3.0 - CASING AND CEMENTING SUMMARY

Section 3.1 - Summary

Hole Size (mm)	Casing Size (mm)	Casing Grade	Casing Weight (kg/m)	Setting Depth (mKB)	How Set
340	340	LS	81.10	42	Driven – cement squeeze if necessary
312	244	H40	48.06	57	Cemented to surface with 100% excess Class G 0-1-0 cement + 2 – 3% CaCl ₂
222	178	J55	29.76	392	Cemented to surface with Class 'G' 0-1-8% plus 1 to 3% CaCl ₂ , followed by Class 'G' neat cement plus 1 to 3% CaCl ₂ . Cement volumes will be calculated with a 50% excess- gel cement and 30% excess – neat cement. Depending upon hole conditions, consideration may be given to running thixotropic cement plus additional loss circulation materials, across porous zone(s).
159	114	J55	15.62	686	Cemented to surface with Class 'G' 0-1-0% plus 1 to 2% CaCl ₂ plus 10% NaCl. Cement volumes will be calculated with a 50% excess on the open hole section and 30% excess on the cased hole section.

Main Hole: 98mm open hole will be drilled from 686m to 727m

Section 3.2 - Wellbore Diagram



Filed: 2012-02-15 EB-2012-0060 Attachment 4 Page 13 of 25

Section 3.3 - Wellhead Summary

Weatherford 13.8 MPa Wellhead:


244mm x 279mm slip on weld on casing bowl for BOP installation

178mm x 229mm slip on weld on casing bowl

229mm x 179mm spool c/w 2 gate valves on side outlets

179mm 13.MPa x 179mm x 20.7 MPa double studded adapter

152mm ANSI 900 Cameron Grove full port ball valve



Filed: 2012-02-15 EB-2012-0060 Attachment 4 Page 14 of 25

SECTION 4.0 - DRILLING PROCEDURES

Section 4.1 - Pre Spud

1. Fresh Water Well Samples

Obtain samples from all fresh water wells located within a 750 metre radius of the proposed well. Have routine water analysis done on all water samples by an independent laboratory in Sarnia. Ensure that copies of these reports are placed in the well files in Enbridge's office

2. Site Preparation

Prepare drilling location as follows:

- a. Locate all drainage tiles crossing lease area
- b. Strip and properly stock pile all soil from the lease
- c. Cut, block and divert drainage tiles as required
- d. Construct adequate berms around lease and access road as required

3. Government Notification of Spud

48 hours prior to spud, notify the Ministry of Natural Resources – Petroleum Resources Section by fax @ (519) 873 – 4645 of the date of commencement of drilling operations

4. Signs

Install rig signs on access road to lease.

5. Safety Meeting

Conduct a pre-spud safety meeting for Rig crews. Tool push and all crewmembers must be present. A similar meeting shall be conducted with the remaining crew(s) as they come on duty. Additional safety meetings shall be conducted as per Section 6.1 of this program.

Section 4.2 - Conductor Casing

1. Drilling Method

Move in and rig up Cable Tool Rig. Measure and record the distance from RF to ground and the RF elevation – include these measurements on the tower sheets and the daily report. Drill and drive 340mm casing to bedrock, to an approximate depth of 42m. Note any occurrence of water and record type of water, depth encountered, and static level of water and/or flow rate. If fresh water is encountered during

drilling, the well must be bail tested for at least 15 minutes, after the casing is landed, to ensure that the fresh water has been shut-off. If the fresh water has not been shut-off, contact Enbridge's office and be prepared to perform a cement squeeze as per Enbridge's requirements.

2. Cement Squeeze (if necessary)

If fresh water is found in the drift and is not shut-off by the conductor casing, a flow rate will be established and a cement squeeze will be performed, using the cement volumes determined by Enbridge. Wait on cement 12 hours and bail the hole dry and monitor the well for at least 15 minutes to determine if the water has been shut-off. If necessary, the process will be repeated until the water is shut-off.

Section 4.3 - Surface Hole & Surface Casing

1. Drilling Method

Drill a 312mm hole 15 metres \pm into the Kettle Point formation, to an approximate depth of 57m. Ensure that drill cutting samples are taken every 3 metres and placed in the sample bags provided by the Ministry of Natural Resources. The sample bags must be labeled with the well name, Township, Lot, Concession and Enbridge's name. Record on daily drilling reports any influx of fluids and/or hydrocarbons, static levels, pressures and any unusual hole conditions.

2. Casing Installation

Depending upon hole conditions encountered, the 244mm casing will be run in the following manner:

- Texas Shoe on bottom of first joint
- Centralizers on the top and bottom of the first joint and coincident with the shoe of the conductor casing
- 244mm casing to surface

3. Cementing Procedures

Move in and rig up Cementers. Ensure pressure recorder is rigged in and serviceable. Pressure charts will be attached to the job ticket. Conduct a pre-job safety meeting to confirm volumes and procedures. Establish circulation using pump truck. The casing and the hole will be circulated with fresh water for 15 minutes to clean the borehole and to fill the casing and hole prior to cementing. Pressure test surface equipment to 14 MPa. Ensure that preflush and mix water are from a clean source and that the water trucks are uncontaminated. Pump preflush of 2.0m³ of fresh water, with the addition of loss circulation material if necessary. Ensure that a minimum of 4 cement samples are taken and represent the cement at the beginning, middle and end of the cement job. Mix and pump sufficient Class 'G' 0-1-0% cement plus 2 to 3% CaCl₂

with a density of 1901 kg/m³ to cement the casing to surface with 100% excess. Displace cement with fresh water – ensure that cement is under displaced and that the bottom joint of casing is full of cement. Shut-in cementing valve at surface and wait on cement at least 12 hours before slacking off casing.

- 4. Install 244mm x 279mm slip on weld on casing bowl for BOP installation. Arrange to have surface hole cuttings solidified and then disposed in an approved manner.
- 5. Release the Cable Tool Rig.

Section 4.4 - Intermediate Hole & Intermediate Casing

1. BOP Installation and Pressure Testing

Move in and rig up Rotary Rig. Measure and record the distance from KB to ground and the KB elevation – include these measurements on the tower sheets and the daily report.

Install Class A (Rotary) BOPs as per MNR requirements. After BOPs are installed and the cement samples indicate that the cement is competent, the rig will proceed to pressure test the BOPs, casing and shoe. Pressure test casing and each component of the BOPs as per Section 6.2. After successfully pressure testing the BOPs and casing, drill out cement and 0.5m of new formation and conduct a PIT, with the hole full of fresh water, using a bottom hole pressure equivalent to 18 kPa/m.

2. Drilling Method

Drill a 222mm hole with fresh water to 5m ± into the F Shale formation, to an approximate depth of 392m. Notify Geologist 12 hours in advance of reaching intermediate casing point, so that they can be on site to determine the proper casing setting depth. When casing setting depth has been determined, circulated the hole clean. Perform a flow check prior to tripping and strap out of the hole. Fast tripping of the drill string is to be avoided in order to eliminate high annular velocities, pressure surges and swabbing (maximum rate of 27 metres per minute). Keeping the hole full of fluid, trip out of the hole and laydown bottom hole assembly and depending upon rotary rig type, standback or laydown drill collars and drill pipe.

The potential for loss circulation exists while drilling through the Detroit River formations (Lucas and Amherstburg formations). If loss circulation is encountered use the loss circulation contingency program located in Section 4.7. Note all lost circulation intervals and monitor and record fluid loss volumes. If pit fluid must be hauled to disposal, keep solid content to a minimum to reduce costs.

Ensure that drill cutting samples are taken every 3 metres and placed in the sample bags provided by the Ministry of Natural Resources. Record on daily tower sheets

any influx of fluids and static levels (water and/or hydrocarbons), gas and/or any unusual hole conditions.

3. Casing Installation

Ensure that the threads are protected while hoisting casing to the floor. Drift all casing prior to running the casing in the well and apply proper API make-up torque to each connection.

Depending upon hole conditions encountered, the 178mm casing will be run in the following manner:

- Guide shoe
- 178mm joint of casing
- 178mm Float Insert or Float Collar
- Tack weld guide shoe, float collar and bottom 2 joints and use API modified pipe dope on all connections
- Centralizers will be installed one metre above the guide shoe, over the bottom of the first 2 collars and every 5 joints to surface
- 178mm casing to surface

4. Cementing Procedures

Move in and rig up Cementers. Ensure pressure recorder is rigged in and serviceable. Pressure charts will be attached to the job ticket. Conduct a pre-job safety meeting to confirm volumes and procedures. Fill hole and establish circulation using pump truck. The casing and the hole will be circulated with fresh water for 15 minutes to clean the borehole and to fill the casing and hole prior to cementing. Pressure test surface equipment to 14MPa for 10 minutes. Preflush and mix water must be obtained from a clean source and the water trucks must be uncontaminated. Pump preflush of 3.0m3 of fresh water, with the addition of loss circulation material if necessary. Ensure that a minimum of 4 cement samples are taken and represent the cement at the beginning, middle and end of the cement job. Mix and pump sufficient 0-1-8 Class 'G' cement plus 1 to 3% CaCl2 (50% excess) followed by 0-1-0 Class 'G' cement plus 1 to 3% CaCl₂ (30% excess) to cement casing to surface. Depending upon the severity of the loss circulation zones, thixotropic cement with additional loss circulation materials may be used to cover the loss zone. If there are no cement returns to surface, a feed rate will be established and the annulus will be grouted to surface. Drop wiper plug and displace cement and bump plug to 3.5 Mpa over final pumping pressure – do not exceed 60% of internal yield pressure of casing. Once plug is bumped and it is determined that the float is holding, bleed casing pressure back to final pumping pressure, close casing valves and bleed off surface line pressure and wash out BOPs. Wait on cement 24 hours before slacking off casing. Remove 244mm x 279mm casing bowl and install 178mm x 229mm casing bowl on the 178mm casing.

Section 4.5 - Production Hole & Production Casing

1. Pressure Testing

Check cement samples for hardness – if cement samples are set to the satisfaction of the Wellsite Supervisor, proceed with installation of the BOPS. Install Class B (Rotary) BOPs as per MNR requirements on 178mm casing bowl. After BOPs are installed and the cement samples indicate that the cement is competent, the rig will proceed to pressure test the BOPs, casing and shoe. Pressure test casing and each component of the BOPs as per Section 6.2. After successfully pressure testing the BOPs and casing, drill out cement and 0.5m of new formation and conduct a PIT, with the hole full of fresh water, using a bottom hole pressure equivalent to 18 kPa/m.

2. Drilling Method

Drill a 159mm hole using brine to prevent the dissolution of the salt layers. Ensure that drill cutting samples are taken every 3 metres and placed in the sample bags provided by the Ministry of Natural Resources. Record on daily tower sheets any influx of fluids and static levels (water and/or hydrocarbons), gas and any unusual hole conditions.

Prior to penetrating the A-2 Carbonate, the Wellsite Geologist and Wellsite Supervisor must be on-site and a BOP drill shall be completed to familiarize all on-site personnel with the proper procedures.

Drill a 159mm hole $1 \pm$ metres into the A-2 Anhydrite formation, to an approximate depth of 686.0m. The final casing point will be determined by the Wellsite Geologist.

If the reef pressure is above 7000kPa, drilling will be suspended and the rig will be moved off location after the 114mm casing is installed and cemented. The rig will be brought back onto location to complete the drilling of the well when the reef pressure is below 7000kPa.

3. Casing Installation

Ensure that the threads are protected while hoisting casing to the floor. Drift all casing prior to running the casing in the well and apply proper API make-up torque to each connection.

Depending upon hole conditions encountered, the 114mm casing will be run in the following manner:

- Guide shoe
- 114mm joint of casing
- Float Insert or Float Collar

Filed: 2012-02-15 EB-2012-0060 Attachment 4 Page 19 of 25

- Tack weld guide shoe, float collar and bottom 4 joints and use API modified pipe dope on all connections
- Centralizers will be installed on bottom 5 joints of casing on every 5th joint to surface
- 114mm casing to surface

4. Cementing Procedures

Move in and rig up Cementers. Ensure pressure recorder is rigged in and serviceable. Pressure charts will be attached to the job ticket. Conduct a pre-job safety meeting to confirm volumes and procedures.

Establish circulation using pump truck. The casing and the hole will be filled with brine and circulated for 15 minutes to clean the borehole and to fill the casing and hole prior to cementing. Pressure test surface equipment to 14 MPa for 10 minutes. Preflush and mix water must be obtained from a clean source and the water trucks must be uncontaminated. Pump preflush of 3.0m³ of clean brine, with the addition of loss circulation material if necessary. Ensure that a minimum of 4 cement samples are taken and represent the cement at the beginning, middle and end of the cement job. Mix and pump sufficient Class 'G' 0-1-0 cement plus 10% NaCl, to cement the 114mm casing to surface plus 50% excess over open hole and 30% excess in cased hole. Drop wiper plug and displace cement with fresh water and bump plug to 3500 kPa over final pumping pressure – do not exceed 60% of internal yield pressure of casing. Once plug is bumped and it is determined that the float is holding, bleed casing pressure back to final pumping pressure, close casing valves and bleed off surface line pressure. Wash out BOPs and split BOP stack at 229mm flange, install 114mm slips and set slips in casing bowl. Wait on cement 24 hours and cut casing and remove BOPs. Cut and bevel 114mm casing and install primary and secondary seals. Install 229mm x 179mm spool piece and and test wellhead seals to 14 Mpa for 10 minutes. Install 179mm 14MPa x 21MPa double studded adapter and ANSI 900 Master Valve and shut-in well. 48 hours after cementing operations have been completed - pressure test casing, wellhead and master valve to 12,410kPa for a minimum of 4 hours – ensure that a digital pressure gauge is installed. Report results to the Enbridge Office - do not proceed with BOP installation until the pressure test has been successfully completed.

If the Master Valve is too high above the drill floor, the BOPs will be installed on the top of the spool piece and when the well is completed, a WR-1 plug will be set in the base of the casing and successfully pressure tested to 8300 kPa. The BOPs will then be removed and the Master Valve installed. Once the Master Valve has been installed and successfully pressure tested, the plug will be retrieved with a Wireline Service company.

Section 4.6 - Main Hole

1. Installation of the BOPs

Check cement samples for hardness – if cement samples are set to the satisfaction of the Wellsite Supervisor, proceed with installation of the BOPS. Install Class B (Rotary) BOPs as per MNR requirements. After BOPs and lubricator are installed and a minimum of 48 hours 'wait-on-cement-time' has passed and the cement samples indicate that the cement is competent, a cement bond log will be run on the 114mm casing. Consideration may be given to moving out the Rotary Rig and moving in a Cable Tool Rig. The Cable Tool Rig will install Class B (Cable Tool) BOPs.

2. Logging

Move in and rig up Wireline Company. With hole full of fresh water, run a Cement Bond Log, both a non-pressure and pressure pass. Run a Gamma-Ray / Neutron Log from TD to the base of the surface casing. Rig out Wireline Company and release.

3. Drilling Method

Each component of the BOPs and the casing will be pressure tested as per Section 6.2. Upon successful completion of the pressure testing of the BOPs, the cement, shoe and 0.5m of new formation will be drilled out and a PIT will be conducted, with the hole full of fresh water, using a bottom hole pressure equivalent to 18 kPa/m.

Drill a 98mm hole through the A-1 Carbonate and 1 metre into the A-1 Evaporite Formation – final TD will be determined by the Wellsite Geologist. While drilling the main hole ensure that drill cutting samples are taken every 3 metres and placed in the sample bags provided by the Ministry of Natural Resources. Record on daily tower sheets any influx of fluids and static levels (water and/or hydrocarbons), gas and any unusual hole conditions.

Drilling of the well may be suspended if sufficient permeability and porosity are encountered prior to reaching the proposed TD. If drilling is suspended, the rig will be moved off location and a variety of pressure tests will be performed on the well during withdrawal / injection operations. If the testing of the well shows that the porosity and permeability of the well are not suitable, a rig will be moved back onto location and the well will be drilled to the original TD-1 metre into the A-1 Evaporite.

Filed: 2012-02-15 EB-2012-0060 Attachment 4 Page 21 of 25

4. Logging

Move in and rig up Wireline Company to run a Gamma-Ray/Neutron/Density Log over the open hole section of the well and run a Casing Inspection Log over the 114mm casing.

5. BOP Removal

Close master valve and nipple down BOPs and install 152mm (6") blind flange. If the master valve was not used for the drilling of the well — move in and rig up Wireline and Tool Companies and install a WR-1 plug in the base of the 114mm casing. Bleed down and fill the well with fresh water and pressure test the plug to 8300 kPa. Upon successful completion of the pressure test, remove BOPs and install master valve. Install a digital pressure recorder and pressure test casing, wellhead and master valve, with the hole full of fresh water to a surface pressure of 12,410kPa for a minimum of 4 hours. Report results to Enbridge Office. Do not rig down until well passes the pressure test. Move in Wireline Company to retrieve WR-1 plug.

6. Rig down rotary rig and move off of location and restore wellsite to Enbridge's specifications.

Section 4.7 - Loss Circulation Procedure

- 1. Before drilling out the casing shoe:
 - Identify sources and location of fresh water and/or brine, loss circulation materials and weight materials
 - b. Ensure BOPs and manifold are properly installed
 - c. Ensure auxiliary tanks are connected to the pumping system and a standby mud pump is hooked up for annular injection in case of severe loss circulation (so that fluid can be pumped down both the drill pipe and annulus simultaneously)
 - d. Pressure test BOPs prior to drill out

2. After drilling out shoe:

- a. Alert water suppliers and haulers
- b. Ensure adequate amounts of fresh water and/or brine are readily available prior to penetrating the Detroit River formation.
- c. Mechanically test BOPs and perform BOP drill prior to penetrating the Detroit River formation.
- 3. Drilling Blind Detroit River formations:
 - a. In an attempt to maintain or re-establish circulation, pump fluid down both the annulus and the drill pipe simultaneously
 - b. Should severe loss circulation occur while drilling, the thief zone may be plugged with cement and/or loss circulation material at Enbridge's discretion.

Filed: 2012-02-15 EB-2012-0060 Attachment 4 Page 22 of 25

SECTION 5.0 - REPORTING PROCEDURES

Section 5.1 - Tower Sheets

Shall be completed daily and shall include:

- 1. Bit size, jars, depth at the beginning of the shift and end of each shift.
- 2. Casing size, grade, weight, and number of joints, centralizers, cement baskets, total length and setting depth.
- 3. Cementing information Service Company, cement type, amount, slurry density, additives, annular fluid returns, volume of displacement fluid and plug down time.
- 4. Water, gas or oil type, depth encountered depth of sample collected and the static level and/or rate of flow.
- 5. Pressure tests individually, surface pressures, fluid density used in the tests, bleed-off rate and duration of test.
- 6. Logging Details type and interval.
- 7. Abandonment details intervals, amount and type of cement, top of plug and time felt.
- 8. Rig release date and time.

Section 5.2 – Worker Injury

Every work related accident or injury shall be reported immediately to the Wellsite Supervisor. The Supervisor shall immediately contact the Ministry of Labour @ 1-800-265-5140 and the Ministry of Natural Resources @ 519-873-4634. The verbal report shall be followed with a written report as per the Occupational Health and Safety Act and the Oil, Gas & Salt Resources Act and Section 13 of the Operational Standards. The Supervisor will also be responsible for notifying the Operator (Enbridge Gas Distribution Inc.) and shall be responsible for the completion of Enbridge's Accident Report Form.

Filed: 2012-02-15 EB-2012-0060 Attachment 4 Page 23 of 25

SECTION 6.0 - SAFETY AND PROCEDURES

Section 6.1 - General Safety

- All works at the wellsite shall be in compliance with the Occupational Health and Safety Act and the Oil, Gas & Salt Resources Act and all associated legislation. In addition, all work at the wellsite shall be done in compliance with good oil field practices. All verbal notifications given to and approvals received from government agencies shall be recorded on the tower sheets.
- 2. The Enbridge 'Job Safety Analysis Form' (JSA) shall be thoroughly reviewed by the Wellsite Supervisor with all onsite personnel through the daily safety meetings and any changes to the JSA will be noted on the Enbridge Safety Meeting / Tool Box Form.
- 3. Daily safety ('tailgate') meetings are to be conducted with each shift and recorded on the Enbridge Safety Meeting / Tool Box Form. Additional safety meetings are to be held with each crew, at the start of the well and safety meetings shall also be held prior to cementing and upon arrival of the logging company and prior to penetrating the Detroit River formations and the A-2 Carbonate formation.
- 4. The Wellsite Supervisor shall ensure that the operations are in compliance with all applicable government regulations and shall complete daily walk around rig inspections and record the results on their daily reports.

Section 6.2 – Well Control

All blowout prevention systems are to be in strict compliance with MNR regulations. The function and pressure testing guidelines required by the regulatory bodies (such as daily function testing of the pipe rams) will be strictly adhered to.

- 1. All pressure tests of blowout prevention equipment will be conducted with fresh water and will be conducted in 2 stages low and high pressure. It is essential that the low pressure test be done first, to prevent the high pressure test from healing leaks that would have been noted at low pressures.
- 2. The following pressure tests will be conducted with fresh water prior to drilling out each casing string and the results recorded on the tower sheets and daily reports:

Rotary:

- a. The blind rams, kill lines and choke manifold and casing will be tested individually for 10 minutes each to:
 - i. Intermediate casing 2000 kPa low & 9000 kPa high
 - ii. Production casing 2000 kPa low and 10000 kPa high

Filed: 2012-02-15 EB-2012-0060 Attachment 4 Page 24 of 25

- b. Run in hole with BHA, drill pipe and drill collars and pressure test the pipe rams, kelly cock, stand pipe, swivel, safety valves, etc. will be tested individually for 10 minutes each to:
 - i. Surface casing 1400 kPa low and 3500 kPa high (using AP)
 - ii. Intermediate casing 2000kPa low & 9000 kPa high
 - iii. Production casing 2000 kPa low and 10000 kPa high
- c. The annular preventer will be tested for 10 minutes to
 - i. Surface casing 1400 kPa low and 3500 kPa high
 - ii. Intermediate casing 2000 kPa low & 9000 kPa high
 - iii. Production casing 2000 kPa low and 10000 kPa high

Cable Tool:

- a. The blind rams, kill lines and casing will be tested individually for 10 minutes each to:
 - i. Intermediate casing 2000 kPa low & 8000 kPa high
 - ii. Production casing 2000 kPa low and 10000 kPa high
- b. Function test the pipe rams / shear rams, safety valves, etc. individually for 10 minutes each to:
 - i. Intermediate casing 2000kPa low & 8000 kPa high
 - ii. Production easing 2000 kPa low and 10000 kPa high
- c. The annular preventer will be tested for 10 minutes to
 - i. Surface casing 1400 kPa low and 3500 kPa high
 - ii. Intermediate casing 2000 kPa low & 8000 kPa high
 - iii. Production casing 2000 kPa low and 10000 kPa high
- d. The lubricator system will be tested for 10 minutes to
 - i. Production casing 2000 kPa low and 8000 kPa high
- e. A full lubricator system will be required when:
 - i. gas is encountered with H₂S content greater than 100ppm,
 - ii. when crude oil flows to surface or is capable of unloading during bailing operations, or
 - iii. when flows of natural gas exceed 7.0 10³m³/D (250Mcfd).
- Upon drilling out the casing, drill 0.5m to 1.0m of new hole and test the formation, with the hole full of fresh water, to a minimum bottom hole pressure of 18 kPa per metre.
- 3. After one day of drilling below the casing shoe, check the entire blowout prevention system and tighten all bolts.

Filed: 2012-02-15 EB-2012-0060 Attachment 4 Page 25 of 25

- 4. Crews should be kept alert and familiar with the blowout prevention equipment. At least one member of the crew who has been trained in blowout prevention and well control procedures must be on the floor at all times.
- 5. Conduct blowout prevention drills prior to drilling out casing and once per week thereafter. Ensure that the drills are recorded in the tour book.
- 6. The blowout preventers are to be function tested once per tour. Ensure that the function test is recorded on the tower sheets.